

INSTALLATION, OPERATION & MAINTENANCE MANUAL OF SMILE - G3 – T12 / T15 / T20



DISCLAIMER

Copyright © Alpha ESS Co., Ltd. 2024. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Alpha ESS Co., Ltd.

The material furnished in this document is believed to be accurate and reliable. The information and recommendations in this document do not constitute commitments or warranties in the form of assignments. The information in this document is subject to change without notice. You may refer to the AlphaCloud Online Monitoring Platform (<https://cloud.alphaess.com>) for the most updated version.

All company and brand products and service names are trademarks or registered trademarks of their respective holders.

COPYRIGHT STATEMENT

This manual is under the copyright of Alpha ESS Co., Ltd. with all rights reserved. Please retain this manual and operate the Product in accordance with all safety and operating instructions in this manual. Please do not operate the product before reading through the manual.

CONTENT

| | |
|---|-----------|
| DISCLAIMER | 1 |
| COPYRIGHT STATEMENT | 2 |
| CONTENT | 3 |
| 1. INTRODUCTION | 7 |
| 1.1. Content and Structure of this Document | 7 |
| 1.2. Target Group | 7 |
| 1.3. Levels of Warning Messages | 8 |
| 1.4. Definition of Abbreviations and Nouns | 9 |
| 2. Safety | 10 |
| 2.1. Intended Use | 10 |
| 2.2. Safety Instructions for Battery | 11 |
| 2.2.1. General Safety Precautions | 11 |
| 2.2.2. Response to Emergency Situations | 11 |
| 2.3. Important Safety Instructions | 12 |
| 2.4. Symbols Explanation | 16 |
| 3. Product Introduction and Application Scenarios | 19 |
| 3.1. Naming Convention | 19 |
| 3.2. System Introduction | 20 |
| 3.3. Product Description | 21 |
| 3.3.1. Inverter Electrical Interface & Connections Introduction | 21 |
| 3.3.2. Inverter Display Interface Introduction | 22 |
| 3.3.3. Battery Display Interface Introduction | 23 |
| 3.3.4. Battery Introduction of SMILE-G3-BAT-8.2P | 24 |
| 3.3.5. Battery Introduction of SMILE-G3-BAT-3.8S | 25 |
| 3.3.6. Battery Introduction of SMILE-G3-BAT-3.6S/4.0S | 26 |

| | |
|---|-----------|
| 3.4. Application Scenarios | 27 |
| 3.4.1. DC-Coupled Energy Storage System | 27 |
| 3.4.2. AC-Coupled Energy Storage System | 27 |
| 3.4.3. Hybrid-Coupled Energy Storage System | 28 |
| 3.4.4. Off-Grid Storage System | 28 |
| 4. Storage and Transport | 29 |
| 4.1. Storage | 29 |
| 4.1.1. Inverter Storage | 29 |
| 4.1.2. Battery Storage | 29 |
| 4.2. Transport | 30 |
| 5. Mounting | 31 |
| 5.1. Check the Outer Packaging | 31 |
| 5.2. Scope of Delivery | 31 |
| 5.3. Requirements for Mounting | 35 |
| 5.3.1. Basic Requirements | 35 |
| 5.3.2. Mounting Environment Requirements | 35 |
| 5.3.3. Mounting Structure Requirements | 36 |
| 5.3.4. Mounting Angle and Stack Requirement | 36 |
| 5.3.5. Mounting Space Requirements | 37 |
| 5.4. Preparing Tools and Instruments | 39 |
| 5.5. Mounting the System | 40 |
| 5.5.1. Mounting the Parallel Battery | 40 |
| 5.5.2. Mounting the Series Battery | 42 |
| 5.5.3. Mounting the Energy Storage Inverter | 50 |
| 5.5.4. Special Feature for Battery SMILE-G3-BAT-3.6S/4.0S | 51 |
| 5.5.5. Mounting the Wi-Fi Module | 52 |
| 6. Electrical Connection | 53 |
| 6.1. Cable Requirements for Connection | 54 |
| 6.2. Grounding Connection | 55 |
| 6.3. AC Connection | 56 |

| | |
|--|------------|
| 6.3.1. Requirements for the AC Connection | 56 |
| 6.3.2. Select Suitable AC Circuit Breaker | 57 |
| 6.3.3. Grid and Backup Connection | 58 |
| 6.3.4. Disassembling the AC Connectors | 60 |
| 6.3.5. Meter Connection | 61 |
| 6.4. PV Connection | 67 |
| 6.5. Electrical Connection between the Inverter and Battery | 69 |
| 6.5.1. Communication Connection between INV and BAT | 69 |
| 6.5.2. System Connection between INV and BAT | 70 |
| 6.6. Communication Connection with Inverter | 77 |
| 6.7. Mount Covers of the Inverter and Battery | 79 |
| 7. Power On and Off the System | 83 |
| 7.1. Power On the System | 83 |
| 7.2. Power Off the System | 84 |
| 8. Commissioning | 85 |
| 8.1. Checks before Power-On | 85 |
| 8.2. Power On the Product before Commissioning | 86 |
| 8.3. Wi-Fi Module Configuration and Basic Parameters Settings | 87 |
| 8.3.1. Wi-Fi Configuration | 87 |
| 8.3.2. Basic Parameters Settings | 89 |
| 8.4. Check System Wiring and Meter Installation | 92 |
| 8.5. Installing New System and Settings on the App | 96 |
| 8.5.1. Download and Install the App | 96 |
| 8.5.2. Register as an Installer | 96 |
| 8.5.3. Overview of Functions for Installer Account | 97 |
| 8.5.4. Install New System on the App | 98 |
| 8.5.5. Instruct the End User to Install the App | 100 |
| 8.6. Register on AlphaCloud | 100 |
| 8.6.1. Register an Installer Account on AlphaCloud | 100 |
| 8.6.2. Install New System on AlphaCloud | 102 |



| | |
|--|------------|
| 9. Maintenance and Troubleshooting | 103 |
| 9.1. Routine Maintenance | 103 |
| 9.2. Troubleshooting | 104 |
| 9.2.1. Common Errors | 104 |
| 9.2.2. Battery Protection Description for SMILE-G3-BAT-8.2P | 112 |
| 9.2.3. Battery Protection Description for Series Battery | 113 |
| 9.2.4. Battery Error Description | 114 |
| 10. Product Removal & Return | 115 |
| 10.1. Removing the Product | 115 |
| 10.2. Packing the Product | 115 |
| 10.3. Disposing of the Product | 115 |
| 11. Technical Data | 116 |
| 11.1. Datasheet of Inverter SMILE-G3 Three Phase Inverter | 116 |
| 11.2. Datasheet of Battery | 119 |
| 11.2.1. Datasheet of Battery SMILE-G3-BAT-8.2P | 119 |
| 11.2.2. Datasheet of Battery SMILE-G3-BAT-3.6S | 120 |
| 11.2.3. Datasheet of Battery SMILE-G3-BAT-3.8S | 121 |
| 11.2.4. Datasheet of Battery SMILE-G3-BAT-4.0S | 122 |
| Appendix 1: System Wiring Diagram | 123 |
| Appendix 2: Regional Application Standard | 131 |

1. INTRODUCTION

1.1. Content and Structure of this Document

This document is valid for product of SMILE-G3 three phase energy storage system which includes inverter SMILE-G3-T12/T15/T20-INV and battery SMILE-G3-BAT-8.2P, and SMILE-G3-BAT-3.6S/3.8S/4.0S.

This document describes the mounting, installation, commissioning, configuration, operation, troubleshooting and decommissioning of the energy storage system as well as the operation of the user interface.

Please read all documentation that accompanies the product. Keep them in a convenient place and available at all times.

Illustrations in this document are reduced to the essential information and may deviate from the real product.

1.2. Target Group

This document is intended for qualified persons. Only qualified persons are allowed to perform the operations marked with a warning symbol in this document.

Qualified persons must have:

- Knowledge of working principle of inverters.
- Knowledge of how to deal with the dangers and risks associated with installing and using electrical devices, batteries and energy storage system.
- Knowledge of the installation and commissioning of electrical devices and energy storage system.
- Knowledge of the applicable standards and directives relevant to the product and its installation.
- Understood and complied with this document, including all safety precautions.
- Understood and complied with the documents of the battery manufacturer and inverter manufacturer, including all safety precautions.

1.3. Levels of Warning Messages

The following levels of warning messages may occur when handling the product.

DANGER

DANGER indicates a hazardous situation that will result in serious injury or even death if not avoided.

WARNING

WARNING indicates a hazardous situation that could result in serious injury or even death if not avoided.

CAUTION

CAUTION indicates a hazardous situation that could result in minor or moderate injury if not avoided.

NOTICE

NOTICE indicates a situation that could result in property damage if not avoided.

INFORMATION provides tips for the optimal installation and operation of the product.

1.4. Definition of Abbreviations and Nouns**A**

AC alternating current

App application

AUX auxiliary

B

BAT battery

BMS battery management system

D

DC direct current

E

EMS energy management system

I

INV inverter

P

PV photovoltaic



2. Safety

2.1. Intended Use

The inverter, batteries and electricity meters together form a system designed to optimize the self-consumption of electrical energy in a household. The inverter transfers energy between AC current and DC current while the battery is used for the storage of energy (typically storing surplus energy produced by solar arrays).

SMILE-G3-T12/T15/T20-INV and SMILE-G3-BAT-3.6S/4.0S are suitable for indoor and outdoor installation.

SMILE -G3-BAT-8.2P and SMILE -G3-BAT-3.8S are only suitable for indoor installation.

The SMILE-G3-T12/T15/T20-INV must only be operated with PV arrays of protection class II in accordance with IEC 61730, application class A. The PV modules must be compatible with this product.

PV modules with a high capacity to ground can be used only when their coupling capacity does not exceed 1.0 μF .

All components must be used in a manner and environment in compliance with the requirements of this manual and in compliance with all relevant local Standards and directives. Any other operation may cause personal injury or property damage.

Alterations to the product, e.g. changes or modifications, are only permitted with the express written permission of AlphaESS. Unauthorized alterations will void the product warranty(s). AlphaESS shall not be held liable for any damage caused by such changes.

Any use of the product other than that described in the Intended Use section does not qualify as appropriate.

The enclosed documentation is an integral part of this product. Keep the documentation in a convenient place for future reference and comply with all instructions contained therein.

The type label must remain permanently attached to the product.

2.2. Safety Instructions for Battery

2.2.1. General Safety Precautions

- Before installing any part of the SMILE G3, please read the Installation Manual completely. If additional hardware is being installed at the same time as the SMILE G3 unit (e.g. a Backup device or a separate AC-coupled PV system), please read the Installation Manual for each component/system before commencing installation of any hardware. The installation of one piece of hardware may create hazards for the installation of another piece of hardware – be sure to read all Manuals to understand the interaction and safety implications of the combined systems.
- Overvoltage or incorrect wiring can damage the battery and cause deflagration, which can be extremely dangerous.
- All types of battery breakdown may lead to electrolyte or flammable gas leakage.
- The battery is not user-serviceable because there is high voltage in the device.
- Read the label with Warning Symbols and Precautions on the right side of the battery.
- Do not connect any AC conductors or PV conductors directly to the battery which should be connected only to the inverter.
- Do not charge or discharge a damaged battery.
- Do not damage the battery by dropping, deforming, impacting, cutting or penetrating it with a sharp object. Battery damage may cause a leakage of electrolyte or fire.
- Do not expose the battery to an open flame.

2.2.2. Response to Emergency Situations

The battery is designed to prevent the danger caused by malfunction.

- In the case of user exposure to the electrolyte or other internal materials of the battery cells, the list below details recommended actions dependent on the type of exposure:
 1. Inhalation: Leave the contaminated area immediately and seek medical attention.
 2. Eye injuries: Rinse eyes with running water for 15 minutes and seek medical attention.
 3. Skin injuries: Wash the affected area thoroughly with soap and seek medical attention.
 4. Ingestion: Induce vomiting and seek medical attention.

If a fire breaks out in the place where the battery is installed, please follow these measures:

- Fire extinguishing methods
 1. A Respirator is not required during normal operations.
 2. Use an FM-200 or CO₂ extinguisher for battery fire.
 3. In the case of a fire in the property but where the fire has not yet reached the battery, if it is safe to do so, use an ABC fire extinguisher and prevent the fire from reaching the battery.
- Firefighting instructions

1. If a fire occurs when charging the batteries, if it is safe to do so, disconnect the battery circuit breaker to shut off the power to the batteries.
2. If the battery is not on fire yet, extinguish the fire before the battery catches fire.
3. If the battery is on fire, do not try to extinguish it but evacuate people immediately.

WARNING

There may be a possible explosion when batteries are heated above 150°C. The battery leaks poisonous gases when it is burning. Do not approach.

- Effective ways to deal with accidents
 1. On land: Place damaged battery in a segregated place and call local fire department or technical service engineer.
 2. In water: Stay out of the water and don't touch anything if any part of the battery, inverter, or wiring is submerged.
 3. Do not use submerged battery again and contact an AlphaESS-Accredited or Battery-Accredited technical service engineer.

2.3. Important Safety Instructions

DANGER**Danger to life due to electric shock when live components or DC cables are touched**

The DC cables connected to a battery or a PV module may be live. Touching live DC cables can result in serious injury or even death due to electric shock. To avoid this danger:

- Disconnect the inverter and battery from voltage sources and make sure it cannot be reconnected before working on the device.
- Do not touch non-insulated parts or cables.
- Do not disconnect the DC connectors under load.
- Wear suitable personal protective equipment for all work on the product.
- Observe all safety information of this document.

DANGER**Danger to life due to electric shock if live system components in backup mode are touched**

Even if the grid circuit breaker and the PV switch of the inverter are disconnected, parts of the system may still be live when the battery is switched on due to backup mode. To avoid this danger:

- Before performing any work on the inverter, disconnect it from all voltage sources as described in this document.

**Danger to life due to electric shock if touching live components or DC cables when working on the battery**

The DC cables connected to the battery may be live. Touching live DC cables can result in serious injury or even death due to electric shock. To avoid this danger:

- Before performing any work on the battery, disconnect the inverter from all voltage sources as described in this document.

**Danger to life due to electric shock if touching live components when the inverter or battery cover is open**

High voltages are present in the live parts and cables inside the system during operation. Touching live parts and cables can result in significant injuries or even death due to electric shock. To avoid this danger:

- Do not open the system cover.

**Danger to life due to electric shock if live components are touched during a ground fault**

When a ground fault occurs, parts of the energy storage system may still be live. Touching live parts and cables can result in significant injuries or even death due to electric shock. To avoid this danger:

- Disconnect the product from voltage sources and make sure it cannot be reconnected before working on the device.
- Touch the cables of the PV array on the insulation only.
- Do not touch any parts of the substructure or frame of the PV array.
- Do not connect PV strings with ground faults to the inverter.

**Danger to life due to electric shock if an ungrounded PV module or array frame is touched**

Touching ungrounded PV modules or array frames can result in significant injuries or even death due to electric shock. To avoid this danger:

- Connect and ground the frame of the PV modules, the array mounting frame and the electrically conductive surfaces to ensure continuous conduction.
- Observe the applicable local regulations.

 **DANGER****Danger to life due to dangerous voltages on the battery**

There is dangerous voltage at the terminal of the battery power cable. Touching the terminal of the battery power cable can result in a lethal electric shock. To avoid this danger:

- Do not open the battery cover.
- Leave the protective caps on the connectors for the battery's power connection until the inverter cables are connected to the battery.
- Disconnect the system from voltage sources and make sure it cannot be reconnected before working on the inverter or the battery.

 **WARNING****Risk of chemical burns from electrolyte or toxic gases**

During normal operation, no electrolyte would leak from the battery and no toxic gases would form. Despite careful construction, if the battery is damaged or a fault occurs, it is possible that electrolyte may leak or toxic gases may form. To avoid this danger:

- Store the battery in a cool and dry place.
- Do not drop the battery or expose it to sharp objects.
- Protect the battery from mechanical damage from vehicles, tools and other objects.
- Only set the battery down on its back or its base.
- Do not open the battery.
- Do not install or operate the battery in potentially explosive atmosphere or areas of high humidity.
- If moisture has penetrated the battery (e.g. due to a damaged housing), do not install or operate the battery.
- In case of contact with electrolyte, rinse the affected areas immediately with water and seek medical attention without delay.

 **WARNING****Danger to life due to burns caused by electric arcs through short-circuit currents**

Short-circuit currents in the battery can cause heat build-up and electric arcs. Heat build-up and electric arcs may result in lethal injuries due to burns. To avoid this danger:

- Disconnect the battery from all voltage sources before performing any work on it.
- Observe all safety information of this document.

 CAUTION**Risk of burns from the inverter's hot surface**

The surface of the inverter can get extremely hot during operation, and touching it can result in burns. To avoid this danger:

- Correctly mount the inverter so that it cannot be inadvertently touched.
- Do not touch hot surfaces.
- Wait for 30 minutes for surfaces to cool down after switching the system off.
- Observe the safety messages on the inverter.
- During operation, don't touch any parts other than the display panel of the inverter.

 CAUTION**Risk of injury due to weight of the inverter and battery**

Injuries may be caused if the product is lifted incorrectly or dropped while being transported or mounted. To avoid this danger:

- Transport and lift the product carefully. Take the weight of the product into account. Use lifting and conveyance aids such as lifting trolleys wherever possible.
- Wear suitable personal protective equipment for all work on the product.

 NOTICE**Damage to the inverter and battery due to electrostatic discharge**

Touching electronic components can result in electrostatic discharge, which can damage or destroy the inverter and battery. To avoid this:

- Ground yourself before touching any component.











 NOTICE**Damage due to cleaning agents or inappropriate cleaning methods**

The use of cleaning agents may cause damage to the product and its components. To avoid this:













- Clean the product and all its components only with a cloth moistened with clear water.
- Never clean the unit with a hose or with the use of a water jet.

2.4. Symbols Explanation




Symbols on the type label of the energy storage inverter:

| Symbol | Explanation |
|---|--|
|  | Beware of a danger zone This symbol indicates that the product must be additionally grounded if additional grounding or equipotential bonding is required at the installation site. |
|  | Beware of electrical voltage The product operates at high voltages. |
|  | Beware of hot surface The inverter can get hot during operation. |
|  | Danger to life due to high voltages in the inverter, observe a waiting time of 5 minutes. High voltages within the live components of the inverter that can cause lethal electric shocks. Prior to performing any work on the inverter, disconnect it from all voltage sources as described in this document. |
|  | WEEE designation Do not dispose of the product together with the household waste but in accordance with the disposal regulations for electronic waste applicable at the installation site. |
|  | Read the Product documentation |
|  | CE marking The product complies with the requirements of the applicable EU directives. |
|  | Certified safety The product is TUV-tested and complies with the requirements of the EU Equipment and Product Safety Act. |
|  | RCM (Regulatory Compliance Mark) The product complies with the requirements of the applicable Australian standards. |
|  | UKCA marking The product complies with the regulations of the applicable laws of England, Wales and Scotland. |

Symbols on the type label and warning label of the battery:

| Symbol | Explanation |
|---|---|
|  | <p>Beware of a danger zone This symbol indicates that the battery must be additionally grounded if additional grounding or equipotential bonding is required at the installation site.</p> |
|  | <p>Beware of electrical voltage The product operates at high voltages.</p> |
|  | <p>Risk of chemical burns</p> |
|  | <p>Risk of explosion</p> |
|  | <p>Risk of electrolyte leakage</p> |
|  | <p>Read the Product documentation</p> |
|  | <p>Refer to the instruction for operation Observe all documentations supplied with the product.</p> |
|  | <p>Use eye protection Wear eye protection for all work on the device.</p> |
|  | <p>Fire, naked light and smoking prohibited</p> |
|  | <p>Avoid close proximity. Do not approach the Product unnecessarily.</p> |
|  | <p>Do not short circuit the battery. Touching the short-circuit connection of the battery can result in serious injuries or even death due to electric shock and massive energy release.</p> |
|  | <p>WEEE designation Do not dispose of the battery together with the household waste but in accordance with the disposal regulations for electronic waste applicable at the installation site.</p> |




| | |
|---|--|
|  | CE marking The product complies with the requirements of the applicable EU directives. |
|  | RCM (Regulatory Compliance Mark) The product complies with the requirements of the applicable Australian standards. |
|  | UKCA marking The product complies with the regulations of the applicable laws of England, Wales and Scotland. |
| UN38.3 | Marking for transport of dangerous goods The product passes the certifications of the UN38.3. |

3. Product Introduction and Application Scenarios

3.1. Naming Convention

SMILE-G3-T20




| Location | Name | Explanation |
|----------|-------|---|
| 1 | SMILE | Residential energy storage system |
| 2 | G3 | Generation 3 for SMILE series |
| 3 | T12 | 12kW Inverter with Solar Connections – Three-phase Hybrid energy storage system |
| | T15 | 15kW Inverter with Solar Connections – Three-phase Hybrid energy storage system |
| | T20 | 20kW Inverter with Solar Connections – Three-phase Hybrid energy storage system |

| Complete Designation | Designation in This Document |
|---|-----------------------------------|
| SMILE-G3-T12-INV SMILE-G3-T15-INV SMILE-G3-T20-INV | Energy storage inverter |
| SMILE-G3-BAT-8.2P | Parallel battery |
| SMILE-G3-BAT-3.6S SMILE-G3-BAT-3.8S SMILE-G3-BAT-4.0S | Series battery |
| SMILE-G3-T12 SMILE-G3-T15 SMILE-G3-T20 | System/Energy storage system/BESS |




3.2. System Introduction



| Object | Name | Explanation |
|--------|--|--|
| 1 | Cable Cover | Covers for the left wiring area (There are two types of covers, one for the Battery Module(s) wiring and a second for the Inverter connections). |
| 2 | SMILE-G3-T12-INV SMILE-G3-T15-INV SMILE-G3-T20-INV | Energy storage inverter |
| 3 | SMILE-G3-BAT-8.2P SMILE-G3-BAT-3.6S SMILE-G3-BAT-3.8S SMILE-G3-BAT-4.0S | Battery |

3.3. Product Description

3.3.1. Inverter Electrical Interface & Connections Introduction




| Position | Designation |
|----------|---|
| 1 | Grounding Points |
| 2 | Communication Ports (BMS, RS485, Meter, DRM**&RRCR, LAN, AUX), Refer to Chapter 6.6 |
| 3 | Wi-Fi Port |
| 4 | Battery Circuit Breaker* |
| 5 | Battery Negative (-) Cable Connector |
| 6 | Battery Positive (+) Cable Connector |
| 7 | Positive and Negative PV Connectors, PV1/ PV2, PV3 |
| 8 | PV Switch* |
| 9 | Backup Connector |
| 10 | Grid Connector (AC Supply) |
| 11 | Parallel Communication Ports (Reserve) |
| 12 | LED Display |

* Battery breaker and PV switch of the inverter are switched off when shipped.









** The DRM is only for regions with AS/NZW 4777.2 safety regulations.

3.3.2. Inverter Display Interface Introduction

LED Display



The upper four LED indicators and one reset button are provided on the display panel. These LED indicators provide information about the operation status of the energy storage system.

| Status | Explanation | Status | Explanation |
|---|--|---|--|
|  | White light The system works normally |  | White light The battery works normally |
|  | Red light The system is in fault |  | No light The battery is in fault |
|  | White light Meter communication works normally |  | White light Connected to the server |
|  | No light Meter lost |  | No light Disconnected to the server |


The lower five LED indicators provide information about the State of Charge (SOC) of the batteries connected to this energy storage system.

| LED Indicator | SOC | Description |
|--------------------------------|-----|------------------|
| LEDs show the SOC of batteries | | SOC < 5% |
| | | 5% ≤ SOC < 20% |
| | | 20% ≤ SOC < 40% |
| | | 40% ≤ SOC < 60% |
| | | 60% ≤ SOC < 80% |
| | | 80% ≤ SOC ≤ 100% |

Note that the LED lights provide an approximation of the State of Charge and should be read as an indication and not as a set value.

3.3.3. Battery Display Interface Introduction

During normal operation of battery, three LED indicators on the front cover provide information the State of Charge (SOC) of the battery with white lights glowing and off or flashing (0.5s on, 1.5s off).



| LED Indicator | No. | SOC | Description |
|--------------------------|-----|-----|------------------|
| LEDs show the SOC status | 1 | | SOC ≤ 10% |
| | 2 | | 10% < SOC ≤ 30% |
| | 3 | | 30% < SOC ≤ 50% |
| | 4 | | 50% < SOC ≤ 60% |
| | 5 | | 60% < SOC ≤ 90% |
| | 6 | | 90% < SOC ≤ 100% |

State Display

The LEDs indicate the operating state of the product.

Standby: All white LEDs are flashing (0.5s on and 0.5s off).

Normal: White LEDs are glowing or flashing (0.5s on and 1.5s off).


Protection: Yellow LEDs are glowing or flashing (0.5s on and 0.5s off).

Error: Yellow LEDs are glowing or flashing (0.5s on and 0.5s off).


Shutdown: All LEDs are off.

3.3.4. Battery Introduction of SMILE-G3-BAT-8.2P

Battery appearance and dimensions




Connection area overview




| Position | Designation |
|----------|-----------------------------------|
| 1 | Battery Power Button |
| 2 | Battery Circuit Breaker |
| 3 | Battery Negative Cable Connector |
| 4 | Battery Positive Cable Connector |
| 5 | BMS COM1 |
| 6 | BMS COM2 (with Terminal Resistor) |
| 7 | Grounding Point |
| 8 | Battery LED Display |

3.3.5. Battery Introduction of SMILE-G3-BAT-3.8S

Battery appearance and dimensions




Connection area overview




| Position | Designation |
|----------|-----------------------------------|
| 1 | Battery Positive Cable Connector |
| 2 | Grounding Point |
| 3 | Battery Negative Cable Connector |
| 4 | Battery Circuit Breaker |
| 5 | BMS COM1 |
| 6 | BMS COM2 (with Terminal Resistor) |
| 7 | Battery LED Display |

3.3.6. Battery Introduction of SMILE-G3-BAT-3.6S/4.0S

Battery appearance and dimensions



Connection area overview




| Position | Designation |
|----------|-----------------------------------|
| 1 | Battery Positive Cable Connector |
| 2 | Grounding Point |
| 3 | Battery Negative Cable Connector |
| 4 | BMS COM1 |
| 5 | Pressure Relief Valve |
| 6 | BMS COM2 (with Terminal Resistor) |
| 7 | Battery Circuit Breaker |
| 8 | LED Display |

3.4. Application Scenarios


SMILE-G3 three phase system (includes inverter SMILE-G3-T12/T15/T20-INV and battery SMILE-G3-BAT-8.2P, SMILE-G3-BAT-3.6S/3.8S/4.0S) can be connected as a DC-Coupled systems (mostly new installation), AC-Coupled systems (mostly retrofit), Hybrid-Coupled systems (mostly retrofit, and increase the PV capacity), and Off-Grid (under development) systems as shown in the following diagrams:

3.4.1. DC-Coupled Energy Storage System



DC-Coupled Energy Storage System – Scheme

3.4.2. AC-Coupled Energy Storage System




AC-Coupled Energy Storage System – Scheme



3.4.3. Hybrid-Coupled Energy Storage System


————— Indicates a power cable
 - - - - - Indicates a signal cable



Hybrid-Coupled Energy Storage System – Scheme

3.4.4. Off-Grid Storage System

————— Indicates a power cable
 - - - - - Indicates a signal cable



Off-Grid (with Generator) Energy Storage System – Scheme

NOTE: In all cases, Normal Loads and Essential Loads must be appropriately protected by earth fault protection devices (e.g. Type A or Type B RCDs, RCBOs) in accordance with appropriate Standards.

Backup/Essential Loads should not exceed the rated capacity of the inverter, even during on-grid operation.

4. Storage and Transport

4.1. Storage

4.1.1. Inverter Storage

The following requirements should be met if the inverter is not put into immediate use:

1. Do not unpack the inverter.
2. Keep the storage temperature at $-40\sim 60^{\circ}\text{C}$ and the humidity at $5\%\sim 95\%$ RH.
3. The inverter should be stored in a clean and dry place and be protected from dust and water vapor corrosion.
4. A maximum of four inverters can be stacked. To avoid personal injury or device damage, stack inverters with caution to prevent them from falling over.
5. During the storage period, check the inverter periodically. Replace any damaged packaging promptly.
6. The inverters stored for more than 2 years should be inspected and tested before being put into service.

4.1.2. Battery Storage

The following requirements should be met if the battery is not put into immediate use:


1. Place batteries according to the signs on the carton during storage.
2. Stack battery cartons in accordance with the stacking requirements printed on the external carton.
3. Store the battery out of reach of children and animals.
4. Store the battery in an area where there is minimal dust and dirt.
5. Handle batteries with care to avoid damage.
6. The requirements for the storage environment are as follows:
 - a. Ambient temperature: $-10\sim 55^{\circ}\text{C}$, recommended storage temperature: $15\sim 30^{\circ}\text{C}$
 - b. Relative humidity: $15\%\sim 85\%$
 - c. Place batteries in a dry, clean, ventilated location free from dust.
 - d. Store batteries in a place that is away from corrosive organic solvents and gases.
 - e. Keep batteries away from direct sunlight.
 - f. Keep batteries at least 2 meters away from heat sources.
7. The batteries in storage must be disconnected from external devices and the indicators (if any) on the batteries should be off.
8. Warehoused batteries should be delivered based on the "first in, first out" stock control.

9. The warehouse keeper should collect battery storage information every month and report to the planning department. Batteries stored for more than 6 months should be assessed and charged periodically.
10. Capacity loss may occur if a lithium battery is stored for a long time. After a lithium battery is stored for 12 months in the recommended storage temperature, the irreversible capacity loss rate is 3%~10%. It is recommended that batteries not be stored for a long period. If the batteries need to be stored for more than 6 months, it is recommended to recharge the batteries to 65~75% of the SOC.

4.2. Transport

During transportation, please follow these guidelines:

1. Use the original packaging for transportation. If the original packaging is not available, place the product inside a suitable cardboard box with adequate protection and seal the carton.
2. Handle with care, choose the corresponding handling method according to the weight, and pay attention to safety. Mechanical aids should always be used in preference to lifting by hand.



3. Keep the packaging dry and away from potential sources of damage during transportation.
4. Secure the Product during transportation to prevent falling or mechanical impact.

5. Mounting
























5.1. Check the Outer Packaging

Before unpacking the product, check the outer packaging for damage, such as holes, signs of mechanical damage or water damage. If any damage is found, do not unpack the product and contact your dealer as soon as possible.


















5.2. Scope of Delivery

Check the scope of delivery and inspect components to ensure they are present and undamaged.

Contact your distributor if the packed components are incomplete or damaged.














| SMILE-G3 Three Phase Inverter | | | | |
|---|---|---|--|---|
|  |  |  |  |  |
| Inverter (×1) | TOP Cover (×1) | Right Cover (×1) | Cable Cover (×1) | PV+ & PV- Connectors (×3) |
|  |  |  |  |  |
| Grid Connectors (×1) | Backup Connectors (×1) | Screw M5*12 (×3) | Wall Anchor (×6) | Wi-Fi Module (×1) |
|  |  |  |  |  |
| Positioning Plate (×1) | Wall Bracket (×1) | COM Connection Cover (×1) | AUX Terminal Block (×2) | Grounding Cable Between INV and 1st Battery (×1) |
|  |  |  |  |  |
| Battery COM Cable Between INV and 1st Series Battery * (×1) | Series Batteries Main Positive Power Cable* (×1) | Series Batteries Main Negative Power Cable* (×1) | Power Cable Between Two Column Series Batteries* (×1) | Grounding Cable Between Two Column Series Batteries* (×1) |
|  |  |  | | |
| COM Cable Between Two Column Series Batteries* (×1) | Quick Installation Guide (×1) | System Wiring Diagram Sheets (×1) | | |

* Optional, used when working with series batteries








| SMILE-G3-BAT-8.2P | | | |
|---|---|--|---|
|  |  |  |  |
| Battery (×1) | Top Wall Bracket (×1) | Battery Cable Cover (×1) | M5 Y Type Terminal (×2) |
|  |  |  |  |
| Wall Anchor ST6*55 (×4) | Gap Gasket for Battery Stacking (×2) | Support for Battery Cable Cover (×1) | Battery Communication Cable (X1) |
|  |  |  |  |
| BAT+ Power Cable (×1) | BAT- Power Cable (×1) | Battery Power-Cable* (×1) | Battery Power+ Cable* (×1) |
|  |  |  |  |
| Wall Gap Shim (×1) | Back Support Stud for Battery (×1) | Cheese Head Screw M5*10 (×2) | Countersunk Screw M5*10 (×8) |
|  | | | |
| Quick Installation Guide (×1) | | | |

* For connecting with SMILE-G3-T4/T6/T8/T10-INV

SMILE-G3-BAT-3.8S














| | | | |
|--|---|--|---|
|  |  |  |  |
| Battery (×1) | Battery Cable Cover (×1) | Top Beam of Wall Bracket (×1) | Right Beam of Wall Bracket (×1) |
|  |  |  |  |
| Left Beam of Wall Bracket (×1) | Left Holder for Wall Bracket (×1) | Right Holder for Wall Bracket (×1) | Grounding Bar (×1) |
|  |  |  |  |
| Wall Anchor ST6*55 (×6) | Support Stud for Battery Cable Cover (×2) | Hexagon Head Large Washer Screw M5*12 (×6) | Flange Nut M5 (×7) |
|  | | | |
| Quick Installation Guide (×1) | | | |

Accessories for Base Unit of SMILE-G3-BAT-3.8S

| | | | |
|---|---|--|---|
|  |  |  |  |
| Base Unit (×1) | Top Wall Bracket (×1) | Position Plate (×1) | Right Connection Plate (×4) |
|  |  |  | |
| Right Connection Block for Base Unit (×4) | Hexagon Head Screw M5*12 (×15) | Hexagon Head Limit Screw M5*10 (×10) | |











SMILE-G3-BAT-4.0S




| | | | | |
|---|---|---|---|---|
|  |  |  |  |  |
| Battery (×1) | Battery Cable Cover (×1) | Top Beam of Wall Bracket (×1) | Right Beam of Wall Bracket (×1) | Left Beam of Wall Bracket (×1) |
|  |  |  |  |  |
| Left Holder for Wall Bracket (×1) | Right Holder for Wall Bracket (×1) | Grounding Bar (×1) | Connector for Wall Brackets* (×2) | Wall Anchor ST6*55 (×6) |
|  |  |  | | |
| Hexagon Head Large Washer Screw M5*12 (×6) | Flange Nut M4 (×7) | Quick Installation Guide (×1) | | |

* For 'battery ready' application, connection between the wall bracket of SMILE-G3-T4/T6/T8/T10-INV and the first wall bracket of SMILE-G3-BAT-4.0S

Accessories for Base Unit of SMILE-G3-BAT-4.0S

| | | | |
|---|---|--|---|
|  |  |  |  |
| Base Unit (×1) | Top Wall Bracket (×1) | Position Plate (×1) | Right Connection Plate (×6) |
|  |  |  |  |
| Right Connection Block for Base Unit (×1) | Hexagon Head Screw M5*12 (×20) | Limit block (×10) | Pan Head Screw M5*10 (×13) |

Accessory Cables for Distanced Horizontal Battery Expansion of SMILE-G3-BAT-3.8S/4.0S

| | | |
|---|---|---|
|  |  |  |
| Series Battery Main Negative Power Cable (×1) | Communication Cable Between Two Column Series Batteries (×1) | Power Cable Between Two Column Series Batteries (×1) |

5.3. Requirements for Mounting



Danger to life due to fire or explosion

Despite careful construction, electrical devices can cause fires.

- Do not mount the energy storage system in areas containing highly flammable materials or gases.
- Do not mount the energy storage system in potentially explosive atmospheres.

5.3.1. Basic Requirements

- SMILE-G3-T12/T15/T20-INV and SMILE-G3-BAT-3.6S/4.0S are suitable for indoor and outdoor installation.
- SMILE-G3-BAT-8.2P/3.8S are only suitable for indoor installation.
- Do not install the inverter in a place where people can easily touch it because the inverter's surface will get extremely hot during operation.
- Do not engage screws into tapped holes using a Hammer Driver, Impact Driver or "Rattle gun". Do not damage screws or threaded holes by tightening with too much torque.
- Do not mount the system in areas with flammable or explosive materials.
- Do not mount the inverter at a place within the reach of children.
- Do not mount the system outdoors in areas of high salt mist likelihood where corrosion may cause damage. An area of high salt mist likelihood refers to a region within 500m from the coast or prone to the sea breeze.

5.3.2. Mounting Environment Requirements

- The system must be mounted in a well-ventilated environment to ensure adequate heat dissipation.
- Do not mount in a location that will be exposed to direct sunlight. When mounted under direct sunlight, the power of the system may be derated due to additional temperature rise and the longevity of the product will be reduced.
- Recommend to mount the system in a sheltered place or mount an awning over it.
- The optimal temperature range for the battery to operate is 15 to 30°C.
- Prefer locations indoors, under cover, or generally protected from the elements and extreme temperatures (e.g. in a garage).
- Do not place the system near water sources such as downpipes or sprinklers.
- If the battery is mounted in the garage, ensure the product is adequately protected from potential mechanical impact.

5.3.3. Mounting Structure Requirements

- The surface to which the system is to be mounted shall be fire-rated where required by local regulations.
- Out of an abundance of caution, it is recommended that the system be mounted on non-flammable building materials, even when not required by local regulations.
- Ensure that the mounting surface is sufficiently sturdy to bear the weight of the Product.
- In residential installation, do not mount the system on drywalls or walls made of gyprock or similar materials with poor sound insulation. The noises generated by the inverter can be noticeable and may be exacerbated by locations with poor insulation or where echoing may occur.


5.3.4. Mounting Angle and Stack Requirement

The battery should be placed on the ground and secured to the wall.

The inverter should be hung on the top of the battery and secured to the wall.

The installation angle requirement is as follows:

- Do not mount the inverter at forward-tilted, side-tilted, horizontal, or inverted positions.




5.3.5. Mounting Space Requirements

- Reserve sufficient space around the energy storage system to ensure sufficient space for installation, maintenance and heat dissipation.
- The side clearance is a recommendation which can be adjusted according to the end users' requirements. Clearances may be up to 100mm less than noted if ventilation is adequate and no restrictions or objects will limit access to the labelling or switches of the product or to the use of tools to remove covers or service/remove the product.

In Australia, according to ASNZ5139-2019-4.2.2.2, the non-combustible material needs to be placed between the wall and the battery unit and must extend 600mm to the left and right of the battery and 900mm above it.


Recommended clearances for SMILE-G3-BAT-8.2P



Recommended clearances for series batteries




























It's advisable to keep the series batteries at least 150mm off the ground to protect them from submergence. They should be mounted on a base unit or using a wall bracket.



Local standards may add additional clearance requirements, particularly regarding clearances between the battery and other electrical appliances.

5.4. Preparing Tools and Instruments

| Category | Tools and Instruments | | |
|-------------------------------|---|---|---|
| Installation |  |  |  |
| | Multimeter (DC voltage range ≥ 1000 V DC) | Current clamp | Hammer drill (with a $\Phi 10$ mm drill bit) |
| |  |  |  |
| | Rubber mallet | Socket wrench SW8 | Socket wrench SW8 |
| |  |  |  |
| | T20/PH2 Screwdriver (torque range: 0~5 Nm), L=150mm | Blade width: 1.2/2.5 Flat head screwdriver | Utility knife |
| |  |  |  |
| | Diagonal pliers | Wire stripper | Cable cutter |
| |  |  |  |
| | Crimping tool (model: PV-CZM-22100) | Bootlace/Ferrule terminal crimper | Disassembly and assembly tool of PV connector |
| |  |  |  |
| | Vacuum cleaner | Heat shrink tubing | Heat gun |
| |  |  |  |
| Marker | Measuring tape | Spirit level | |
| Personal Protective Equipment |  |  |  |
| | Safety gloves | Safety goggles | Anti-dust respirator |
| |  | | |

| | | | |
|--|--------------|--|--|
| | Safety shoes | | |
|--|--------------|--|--|

5.5. Mounting the System

5.5.1. Mounting the Parallel Battery

Mounting steps for battery SMILE-G3-BAT-8.2P, please follow the below steps.

a. Remove the battery from the carton and transport it to the installation site with a trolley or other manual handling aid capable of safely moving the product weight.

Secure the product during any movement or transport.

b. Secure the provided back support to the right lower corner of the battery back (tool: SW10 hexagon sleeve, torque: 3.5Nm).

Place the battery against the wall at the required final position. The battery should be level (check with spirit level) before marking the holes in the wall. Where the ground requires levelling beneath the battery, or where the battery is to be mounted on a sub-surface designed to provide level mounting, the levelling surface should be secure and solid (if using a cement pad) before locating the battery and marking the wall for the mounting positions.

c. Pre-mount the top wall bracket to the battery top and mark drill positions.

Remove the top wall bracket and cover the top of the battery with a plastic bag. Then drill 3 holes on the wall with drill $\Phi 10$ and a depth of about 70mm. Clean the holes and insert screw anchors into the drilling holes.

After removing the plastic bag, fix the top wall bracket on top of the battery (tool: T20 screwdriver, torque: 2.5Nm), secure the top wall bracket to the wall using the provided screws by using the SW10 hexagon sleeve.

If you want to mount additional batteries side by side, please repeat the mounting steps from a to c, and then jump to step h.

d. If you want to add another battery on top of the first battery, take out the 2 gap gaskets for battery stacking, 4 cheese head screws M5X10 and 2 hexagon head screws M5X10, and tighten them (tool: T20 screwdriver, torque: 2.5Nm) to the top of the bottom battery.


e. Remove another battery from the carton and transport it to the installation site. Place a PE bag at the bottom of the battery before laying it down, then remove the 2 feet located at the bottom of the battery (tool: T20 screwdriver).

f. Hold the side handles, lift the battery onto the bottom battery, and align the battery's outer contour.








g. Repeat the mounting steps from b to c.

h. Take out the support for battery cable cover from the battery package and tighten it to the lower left of the battery housing with countersunk head screws M5X10 (tool: T20 screwdriver, torque: 2.5Nm).

If two batteries are not aligned perfectly due to uneven wall, please put provided wall gap shim behind the top wall bracket.



Note: Steps 5~9 are only for batteries stack mounting



5.5.2. Mounting the Series Battery


5.5.2.1 Wall Bracket Installation for One Series Battery Installation

Wall bracket installation for one battery installation, please follow the below steps.





- a. Take out the top, left and right beams of the wall bracket from the package and assemble them with M5 nuts (tool: SW8 hexagon sleeve, torque: 2.5Nm).
- b. Select a suitable height for the wall bracket location. Please reserve enough height if you want to add more batteries later.

Mark the upper middle drilling position of the wall bracket and drill the marked hole with a $\Phi 10$ drill. Insert the screw anchor into the drill hole, and pre-tighten the wall bracket horizontally with the provided screw (tool: SW8 hexagon sleeve, torque: 4Nm). Retain 5~10mm from the screw head to the wall.

- c. Hang the wall bracket on the screw head, adjust its horizontal position, then mark the other drilling positions and drill the marked holes with drill $\Phi 10$.
- d. Secure the wall bracket to the wall (tool: SW8 hexagon sleeve, torque: 6Nm).
- e. Take out the left holder and right holder for wall bracket from the package and tighten them to the lower left and lower right of the battery back (tool: T20 screwdriver, torque: 2.5Nm).
- f. Horizontally lift the battery using the handles at two sides and let the top hooks on the back of the battery slide from right to left in the upper beam of the wall bracket.
- g. Secure the battery to the wall bracket and tighten them with two M5*12 screws (tool: T20 screwdriver, torque: 2.5Nm).



* This recommended value "440mm" is for wall bracket location of the bottom battery. Depending on the number of expansion batteries mounted later, meanwhile it is advisable to have a minimum of 150~200mm off the ground to protect from submergence.



5.5.2.2 Wall Bracket Installation for Multiple Series Batteries Installation


When mounting multiple series batteries with wall brackets for the first time, please follow the below steps.

a. Take out the top, left and right beams of the wall bracket from the package, and assemble them with M5 nuts (tool: SW8 hexagon sleeve, torque: 2.5Nm).


Align the upper hole of the lower wall bracket to the lower rivet of the upper wall bracket, assemble them with M5 nuts (tool: SW8 hexagon sleeve, torque: 2.5Nm), and then combine several wall brackets into a whole.






b. For other mounting steps, please see chapter 5.5.2.1 Wall Bracket Installation for One Series Battery Installation and follow step b to step g.

c. Take out the grounding bar from the package and use it to connect the lower left corner of the upper battery and the upper left corner of the lower battery (tool: T20 screwdriver, torque: 2.5Nm).



* This recommended value "870mm" is for wall bracket location of the second battery seeing from the bottom up. This value may adjust depending on the number of expansion batteries mounted later.





5.5.2.3 Wall Bracket Installation for Batteries Expansion Installation

For additional batteries installation (from bottom to top), the expansion batteries should be mounted below existing batteries, please follow the below steps.


a. Take out the top, left and right beams of the wall bracket from the package, and assemble them with M5 nuts (tool: SW8 hexagon sleeve, torque: 2.5Nm).

Align the upper holes of the lower wall bracket to the lower rivets of the upper wall bracket, and mark the drilling position of the newly wall bracket.

b. Remove the newly assembled wall bracket and drill the marked hole with drill $\Phi 10$. Insert screw anchors into the drilling holes, tighten the screws to secure the wall bracket to the wall (tool: SW8 hexagon sleeve, torque: 6Nm).

c. For other mounting steps, please see chapter 5.5.2.1 Wall Bracket Installation for One Series Battery Installation and follow step b to step g.

d. Take out the grounding bar from the package and use it to connect the lower left corner of the upper battery and the upper left corner of the lower battery (tool: T20 screwdriver, torque: 2.5Nm).



5.5.2.4 Base Installation for Several Series Batteries Installation

When mounting multiple series batteries with base installation for the first time, please follow the below steps.

a. Take out the base unit and tighten two hexagon head limit screws M5X12 to the designated location of the base unit's top (tool: T20 screwdriver, torque: 2.5Nm).

Take out the right connection block for base unit from the package and tighten it to the right side of the base unit back.

Take out the position plate and place it against the wall. Place the base unit against the position plate and adjust the feet to level the base unit.

b. Lift the battery by using the handles at two sides, align the bottom holes of the first battery to the screw heads on the top of the base unit. Take out 2 cheese head screws M5X10 and tighten them to battery top's designated location for later position limit. Take out the left holder and right holder for wall bracket and tighten them to the lower left and lower right of the battery back.

c. Secure the battery to the base unit, tighten them with one screw M5X12 from the lower left of the battery (tool: T20 screwdriver, torque: 2.5Nm).

d. Take out one right connection plate from the base unit package, use it to connect the lower right corner of the first battery and the upper right corner of the base unit (tool: T20 screwdriver, torque: 2.5Nm).

e. Lift the second battery by using the handles at two sides, align the bottom holes of the second battery with the screw heads on the top of the lower battery. Take out 2 cheese head screws M5X10, and tighten them to battery top's designated location for later position limit. Take out the left holder and right holder for wall bracket, and tighten them to the lower left and lower right of the battery back.

Continue mounting more batteries by repeating this step.


f. Take out the grounding bars from the battery package, and use it to connect the lower left corner of the upper battery and the upper left corner of the lower battery (tool: T20 screwdriver, torque: 2.5Nm).

g. Take out the right connection plates from the base unit package, use them to connect the lower right corner of the upper battery and the upper right corner of the lower battery (tool: T20 screwdriver, torque: 2.5Nm).

h. Pre-mount the top wall bracket to the upper battery top and mark drilling positions.

i. Remove the top wall bracket and cover the top of the battery with a plastic bag. Then, drill 3 holes in the wall with a $\Phi 10$ drill to a depth of about 70mm and clean the holes and insert screw anchors into the drill holes.


j. After removing the plastic bag, tighten the top wall bracket to the top of the battery (tool: T20 screwdriver, torque: 2.5Nm). Secure the top wall bracket to the wall with the provided screws (tool: SW8 hexagon sleeve, torque: 6Nm).




2 to 6 batteries are suitable for the SMILE-G3 three phase energy storage inverter.

For batteries base installation, there was a tiny difference in **stacking positioning materials** between these series batteries.

For SMILE-G3-BAT-3.6S/4.0S, installers need to mount two **limit blocks** to the top of the batteries for stacking positioning of upper battery.



For SMILE-G3-BAT-3.8S, installers need to mount two **hexagon head limit screws M5X10** to the top of the batteries for stacking positioning of upper battery.




5.5.3. Mounting the Energy Storage Inverter

Mount the inverter with wall bracket, please follow the below steps.


a. Fit the bottom notch of the inverter's positioning plate into the top wall bracket of the battery against wall, mark the positions of the drilling holes.

b. Cover the top of the battery with plastic bag and drill 6 holes on the wall with drill $\Phi 10$, insert the screw anchors into the drilling holes.


c. Secure the wall bracket of the inverter to the wall, tighten the screws (tool: SW8 hexagon sleeve, torque: 6Nm).



d. Hook the inverter into the wall bracket. Ensure that the inverter is securely in place.



e. Secure the inverter to the wall bracket. To do so, insert screws M5X12 into the side threaded holes on both sides of the inverter anchorage bracket respectively and tighten them.



5.5.4. Special Feature for Battery SMILE-G3-BAT-3.6S/4.0S

Wall-Mounted Battery Disassembling


CAUTION

Risk of injury due to the weight of the battery

Injuries may be caused if the product is lifted improperly or dropped while being transported or mounted. To avoid this danger:


- Transport and lift the product carefully. Take the weight (43.2kg) of the product into account and use lifting and conveyance aids such as lifting trolleys.
- Ensure that at least two individuals are present for mounting and disassembling the product.
- Wear suitable personal protective equipment for all work on the product.

When disassembling a battery that has been mounted with wall bracket and is not directly connected to the inverter, always hold the handles on both sides of the battery firmly and slide it to the right. Once the arrow on the upper left of the cover aligns to the left protruding side of the upper battery, carefully lift the battery forward and off the wall bracket.




5.5.5. Mounting the Wi-Fi Module

a. Remove the protective cover of Wi-Fi port at the left of the inverter, directly below the backup connector.



b. Tighten the Wi-Fi module onto the inverter with two M4×12 screws provided (Tool: T20 screwdriver, torque: 1.6Nm). DO NOT OVERTIGHTEN – do not damage the plastic housing of the Wi-Fi module. Note that AlphaESS always recommends a LAN cable connection over the use of a Wi-Fi module.



6. Electrical Connection

Precautions

 DANGER

Electric Shock Hazard - Before connecting cables, switch OFF all circuit breakers and switches connected to the inverter and batteries.

 CAUTION

- Damage to the energy storage system caused by incorrect cable connections is not covered under warranty.
- Only certified electricians accredited by AlphaESS are allowed to connect cables.
- Appropriate PPE must be worn when installing or connecting the product.

 NOTICE

The cable colors shown in the electrical connection diagrams provided in this chapter are for reference only.

Select cables in accordance with local cable specifications (green-and-yellow cables are only used for PE).

6.1. Cable Requirements for Connection

| No. | Cable | Type | Conductor Cross Section Area Range | Outer Diameter | Source |
|------|-----------------------------|--|--|----------------|---|
| 1 | Battery power cable | Standard PV cable (recommended type: H1Z2Z2-K) | 16mm ² for parallel battery SMILE-G3-BAT-8.2P 10mm ² for series battery SMILE-G3-BAT-3.6S/3.8S/4.0S | N/A | Delivered with the battery Delivered with the inverter |
| 2 | Battery communication cable | Standard network cable (recommended type: Cat5e, UTP, UV-resistant for outdoor use) | 0.12~0.2mm ² (AWG26~AWG24) | 4~6mm | Delivered with the battery |
| 3 | PV Power cable | Standard PV cable (recommended type: H1Z2Z2-K) | 4~6mm ² | 5~8mm | Purchased by the installer |
| 4* | Signal cable | Standard network cable (recommended type: Cat5e, SFTP, UV-resistant for outdoor use) | 0.12~0.2mm ² (AWG26~AWG24) | 4~6mm | Purchased by the installer |
| 5** | Signal cable | Two-core outdoor shielded twisted pair copper cable | 0.5~1.5mm ² | 4~6mm | Purchased by the installer |
| 6*** | Signal cable | Outdoor shielded twisted pair copper cable | 0.5~1.3mm ² | 4~6mm | Purchased by the installer |
| 7 | AC power cable | Five-core (L1, L3, L3, N and PE) outdoor copper cable | 6~10mm ² | 11~26mm | Purchased by the installer |
| 8 | PE cable | Single-core outdoor copper cable | 4~10mm ² | N/A | Purchased by the installer |

* For RS485, LAN, three phase meter (with CT), DRM communication connection with inverter.

** For three phase meter (without CT) communication connection with inverter.

*** For AUX communication connection with inverter.

6.2. Grounding Connection


CAUTION

Electric Shock Hazard


Before doing electrical connection, please ensure the PV switch & all AC and DC circuit breakers in the energy storage system are switched OFF and cannot be accidentally or unintentionally reactivated.

A grounding point is provided at the upper left of the energy storage inverter. Prepare M5 Eye/Ring terminals, strip the grounding cable insulation, insert the stripped conductor into the ring terminal lug and crimp with a crimping tool. Connect the grounding terminal to the inverter (tool: T20 screwdriver, torque: 2.5Nm).


Additional grounding connection for inverter:



Grounding connection for inverter and series battery:



Grounding connection for inverter and parallel battery:



6.3. AC Connection

6.3.1. Requirements for the AC Connection

AC cable requirements as follows:

- Conductor type: copper wire (tinned copper preferred)
- Current carrying capacity depends on the Model selected and should be such that the AC cable can carry the full current of the AC supply and the Backup output:

Note: Account for temperature derating and voltage drop/rise when selecting conductor diameter. 110°C or higher rated cable derates slower as temperatures increase.

- External diameter: 11mm to 26mm for grid connector and backup connector
- Grid and backup conductor cross-section recommendation: 6-10 mm²
- Insulation stripping length: 12mm
- Sheath stripping length: 75mm to 80mm

DANGER

You must protect each inverter with an individual grid/backup circuit breaker in order to ensure that the inverter can be disconnected safely.

CAUTION

Residual-current monitoring unit

The inverter does not require an external residual-current device when operating.

If local regulations or a particular installation configuration requires the use of a residual-current device, or a Hybrid-coupled storage system with a big coupling capacity from the PV array and PV inverter, the following must be observed:

The inverter is compatible with type A residual-current devices with a rated residual current of 100mA or higher. Each inverter in the system must be connected to the utility grid via a separate residual-current device.

CAUTION

For Australia and New Zealand installation sites, the neutral cables of grid side and backup side must be connected together, otherwise the backup output function will not work normally.

6.3.2. Select Suitable AC Circuit Breaker

The general requirements for the selection of circuit breakers are determined by standards and country-specific provisions. The following factors should be considered when selecting a suitable circuit breaker:

Factors influencing the current-carrying capacity of the cable: type of cable used, ambient temperature around the cable, type of cable routing, bundling of cables.

Other influencing factors: loop impedance, mutual heating of circuit breakers, ambient temperature at the circuit breaker, selectivity, type of connected device.

If these factors are ignored, it will increase the risk of the circuit breaker tripping under normal operating conditions.

Selecting circuit breakers for the AC supply and Backup output is dependent on the maximum current of the backup circuit and the inverter (if it is force-charged), the model of MCBs used and their derating current rating considering their maximum temperatures. Supplier datasheet shows detailed temperature derating for their MCBs. Ensure the MCBs used are appropriate for the current and the operating temperature. Otherwise, the risk of the circuit breaker tripping will increase under normal operating conditions.

AC connection recommendation for SMILE-G3-T12-INV:

| Description | Max. Current | Breaker Type | Recommended Cable Cross Section |
|-------------|--------------|--------------|---------------------------------|
| Grid Side | 24.6 A | 40 A | 6 to 10 mm ² |
| Backup Side | 19.1 A | 32 A | 6 to 10 mm ² |

AC connection recommendation for SMILE-G3-T15-INV:

| Description | Max. Current | Breaker Type | Recommended Cable Cross Section |
|-------------|--------------|--------------|---------------------------------|
| Grid Side | 29 A | 50 A | 6 to 10 mm ² |
| Backup Side | 23.9 A | 40 A | 6 to 10 mm ² |


AC connection recommendation for SMILE-G3-T20-INV:

| Description | Max. Current | Breaker Type | Recommended Cable Cross Section |
|-------------|--------------|--------------|---------------------------------|
| Grid Side | 36.2A | 50 A | 6 to 10 mm ² |
| Backup Side | 31.9 A | 50 A | 6 to 10 mm ² |


6.3.3. Grid and Backup Connection

The steps for connecting the grid connector as follows:


1. Disconnect the PV switch, grid, backup and battery circuit breaker and secure against reconnection. Ensure that the batteries are switched off.
2. Pay attention to the labels on the AC plug connectors to prevent subsequent confusion with the grid connector for connection to the backup loads.
3. Unscrew the swivel nut of the AC plug connector and remove the terminal from the AC plug connector.




4. For a cable diameter of $\geq 19\text{mm}$, remove the inner sealing ring from the AC plug connector.




5. Route the AC cable through the swivel nut and connector housing.




6. Dismantle the AC cable by 75mm to 80mm. Strip the insulation of L1, L2, L3, N and the grounding conductor 12mm. In the case of fine stranded conductor L1, L2, L3, N and PE are to be fitted with bootlace ferrules.




- Insert the conductors L1, L2, L3, N, and grounding conductor into the terminal block according to the labeling and tighten the terminal block screws (tool: PH2 screwdriver, torque: 1.3Nm).




- Ensure that the conductors are correctly assigned and firmly seated in the terminal.
- Insert the terminal into the connector housing. The terminal must snap audibly into place.



- Tighten the swivel nut on the connector housing.




- Remove the protective cap from the grid connection socket.
- Insert the grid plug connector into the grid connection socket. The grid plug connector must snap audibly into place.



- Take out two fuse terminal blocks provided with grid plug connector, insert them onto the bracket of the AC plug connector from two sides.


The steps for backup connection are the same as the grid connection.



6.3.4. Disassembling the AC Connectors

The steps for disassembling the AC connectors as follows:


1. Disconnect the PV switch, grid, backup and battery circuit breaker and secure against reconnection. Ensure that the batteries are switched off.
2. Unscrew the left-hand and right-hand screws inside two fuse terminal block and remove two fuse terminal blocks.
3. Hold the side brackets of the AC connectors and pull outward.
4. Tight the screw inside the fuse terminal block (tool: PH2 screwdriver, torque: 0.5 Nm).
5. Reattach the protective caps on the AC sockets.



6.3.5. Meter Connection

| Item | Current | Scenarios |
|--------------------------|---------|--------------------------------|
| DTSU666-3*230V 5(80)A | 80A | Three-phase meter (without CT) |
| DTSU666-3*230V 100A/40mA | 100A | Three-phase meter (with CT) |
| DTSU666-3*230V 250A/50mA | 250A | Three-phase meter (with CT) |

Loosen the strain relief nuts of the cable glands on the COM connection cover of inverter, and unscrew the 4 screws on the corners, then you will see meter communication ports.




6.3.5.1 Meter Wiring

Pass the meter communication cable through the cable gland of the COM connection cover but don't tighten the strain relief nut of the cable gland. Insert the RJ45 plug of the meter communication cable into the METER communication port of the inverter.


The other steps for meter connection as follows:

1. DSTU666-3*230V 5(80)A: Three phase meter (without CT) connection



Meter communication cable requirements: two-core outdoor shielded twisted pair copper cable (flexible), conductor cross-section $0.5\sim 1.5\text{mm}^2$, wires terminal should be fitted with bootlace ferrules.

2. DSTU666-3*230V 100A/40mA, DTSU666-3*230V 250A/50mA: Three phase meter (with CT) connection



Meter communication cable requirements: standard network cable (recommended type: Cat5e, SFTP, UV-resistant for outdoor use).
The connections are marked clearly on the meter.

Wiring location description of Chint three phase meter (with CT)

| Grid CT | PV CT | GRID |
|-------------------|--------------------|-----------|
| 1-----IA* (White) | 31-----IA* (White) | 2-----L1 |
| 3-----IA (Blue) | 33-----IA (Blue) | 5-----L2 |
| 4-----IB* (White) | 34-----IB* (White) | 8-----L3 |
| 6-----IB (Blue) | 36-----IB (Blue) | 10----- N |
| 7-----IC* (White) | 37-----IC* (White) | |
| 9-----IC (Blue) | 39-----IC (Blue) | |

| CT Group | Grid-> Load | | | | | | PV->Load | | | | | | | |
|----------|-------------|------|-------|------|-------|------|----------|---|-------|------|-------|------|-------|------|
| | IA* | IA | IB* | IB | IC* | IC | | | IA* | IA | IB* | IB | IC* | IC |
| Terminal | 1 | 3 | 4 | 6 | 7 | 9 | X | X | 31 | 33 | 34 | 36 | 37 | 39 |
| Colour | White | Blue | White | Blue | White | Blue | | | White | Blue | White | Blue | White | Blue |

NOTICE

Be VERY careful when wiring or checking these connections because the connections appear reversed when the meter is secured in place on the Din Rail. Always physically check the label on the meter when wiring any CTs or grid reference wires.


6.3.5.2 Meter Configuration

Meter Setting on the Meter's Display


If connecting Chint DTSU666 meters without CTs, two meters are required if there is any AC coupled PV inverter, one for the Grid Import/Export and one for the AC coupled PV inverter measurements.

| Model | Grid Meter Address | PV Meter Address |
|------------------------------------|--------------------|------------------|
| DTSU666-3*230V 5(80)A (without CT) | 1 | 2 |
| DTSU666-3*230V 100A/40mA (with CT) | 1 | N/A |
| DTSU666-3*230V 250A/50mA (with CT) | 1 | N/A |


1. Meter setting for type DTSU666-3*230V 5(80)A, which is three-phase meter (without CT)
 When the meter is used as grid meter, the default address is 1. The installer doesn't need to make any other settings.




If installer wants to have a check, please follow the steps below.



When the meter is used as PV meter, please follow the steps below to complete the address setting.




2. Meter setting for type DTSU666-3*230V 100A/40mA and DTSU666-3*230V 250A/50mA, three-phase meter (with CT)



The default address is 1. The installer doesn't need to make any other settings.

If installer wants to have a check, please follow the steps below.



Meter Settings on AlphaCloud

Step 1:

When the system work mode is selected as "DC", click the slider under the item "Grid Meter" to turn the "Meter" icon orange.

When the system work mode is selected as "AC" or "Hybrid", click the sliders under the items "Grid Meter" and "PV side meter" to turn the "Meter" icons orange.

Step 2:

Click "Save" and wait a few minutes to refresh the page.

When the "Meter Model" displays DTSU666 model, the setting is successful.

CAUTION

Do not modify the "Meter CT Ratio".

Meter Information

Grid Meter

Meter CT ⓘ

CT

Meter CT Ratio ⓘ

Meter Model

PV Side Meter

Meter CT ⓘ

CT

Meter CT Ratio ⓘ

Meter Model

Save

Meter Settings on AlphaESS App

Step 1:

When the system work mode is selected as "DC", only tick the "Meter" icon on the right of the "Grid Meter".

When the system work mode is selected as "AC" or "Hybrid", tick the two "Meter" icons on the right of the "Grid Meter" and the "PV Meter".

Step 2:

Click "Submit" and enter the "System information" page to check the meter model. When the "Meter Model" displays DTSU666 model, the setting is successful.

CAUTION

Do not modify the "CT" ratio.

System Configuration

Connect to the hotspot Router Configuration System Configuration

Work Mode ? DC >

PV-inverter PV Capacity ? 10 kW

Energy Storage Inverter PV Capacity ? 10 kW

Grid Meter ? CT Meter

CT ? 1

PV Meter ? CT Meter


Safety Regulations AS4777.2:2020 >

Regional application standard ? Australia A

Max.Feed-in(%) ?



The Display Order of Parameters



6.4. PV Connection



Danger to life due to electric shock if live components or DC cables are touched

The DC cables connected to a battery or a PV module may be live. Touching live DC cables can result in serious injury or even death due to electric shock. To avoid this danger:

- Disconnect the inverter and battery from voltage sources and make sure it cannot be reconnected before working on the device.
- Do not touch non-insulated parts or cables.
- Do not disconnect the DC connectors under load.
- Wear suitable personal protective equipment for all work on the product.
- Observe all safety information in this document.



Risk of the inverter due to overvoltage

The inverter can be destroyed if the open-circuit voltage of the PV modules exceeds the maximum input voltage of the inverter.

- If the open-circuit voltage of the PV modules exceeds the maximum input voltage of the inverter, do not connect any strings to the inverter and check the design of the PV system.



Risk of product damage due to ground fault on DC side during operation

Due to the transformerless topology of the inverter, ground faults on DC side during operation can lead to irreparable damage. Damages to the inverter due to a faulty or damaged DC installation are not covered by warranty. Although the inverter is equipped with a protective device that checks whether a ground fault is present during the starting sequence, the inverter is not protected during operation.

- Ensure that the DC installation is carried out correctly and no ground fault occurs during operation.



Risk of the inverter damage due to sand, dust and moisture ingress if the PV inputs are not closed


The inverter is properly sealed only when all unused PV inputs are closed with sealing plugs. Sand, dust and moisture penetration can damage the inverter and impair its functionality.

- Seal all unused PV inputs with sealing plugs.

Please ensure the follows before connecting PV strings to the inverter:

- Make sure the open voltage of the PV strings will not exceed the max. DC input voltage (1000Vdc). Violating this condition will void the warranty.
- Make sure the polarity of the PV connectors is correct.
- Make sure the PV-switch, circuit breakers of battery, AC-BACKUP and AC-Grid are all isolated/in their "off" states.
- Make sure the PV resistor to ground is higher than 200K Ohms.

The inverter uses the Vaconn D4 PV connectors. Please follow the picture below to assemble the PV connectors. PV conductor cross section requirements: 4~6 mm².




6.5. Electrical Connection between the Inverter and Battery


6.5.1. Communication Connection between INV and BAT

Communication cable connection between inverter and SMILE-G3-BAT-8.2P:


- a. Take out the battery communication cable from the battery packaging.
- b. Pass the battery communication cable (BMS cable) through the cable gland of the COM connection cover of energy storage inverter. Do not tighten the strain relief nuts of the cable glands yet.
- c. Insert the RJ45 plug into the BMS communication port on the inverter communication ports labelled "BMS".
- d. Only secure the COM connection cover in place after the Meter communication cable, the BMS cable and the LAN cable (if used) have been clipped into their respective ports.
- e. When securing the COM connection cover over the communication ports, tighten the cover in place and then lightly push the communication cables into the cover as you tighten the strain relief nuts onto the cables. This will ensure the communication cables are well-seated in the RJ45 ports.
- f. The battery communication ports of SMILE-G3-BAT-8.2P are on the left side. Disassemble the battery communication connector components, unscrew the swivel nut, press the cable support sleeve out of the threaded sleeve.
- g. Thread the swivel nut and threaded sleeve over the battery communication cable. At the same time, thread the cable through the opening in the cable support sleeve. Insert the RJ45 plug into the BMS communication port of the battery and screw the threaded sleeve. Press the cable support sleeve into the threaded sleeve. Screw the swivel nut onto the threaded sleeve.



Inverter side




Battery SMILE-G3-BAT-8.2P side



Communication cable connection between the energy storage inverter and series batteries:

- Take out the series battery communication cable between inverter and first series battery from the inverter packaging.
- Other connection steps are the same as the last page from step b to step g.



6.5.2. System Connection between INV and BAT



Danger to life due to short-circuit of the battery

Touching the short-circuit connection of the battery can result in significant injuries or even death due to electric shock and massive energy release.

- Switch off the battery breaker which is located at the left side of the battery.
- Please connect both ends of one battery power cable completely before connecting the next power cable to avoid short-circuiting of the positive and negative battery power cables.

Please pay attention to the cable type. There are 3 kinds of cables.

| No. | Picture | Description |
|-----|---------|---|
| 1 | | Red power cable: connect BAT+ of parallel battery and the BAT+ of inverter connect BAT+ of two parallel batteries |
| 2 | | Black power cable: connect BAT- of parallel battery and the BAT- of inverter connect BAT- of two parallel batteries |
| 3 | | The battery communication cable: connect the COM ports of two parallel batteries |

Power cables connection between inverter and parallel battery SMILE-G3-BAT-8.2P:

- a. Take out the battery power cables from the battery packaging.
- b. Press the buckle with a flat-head screwdriver (blade width: 2.5mm) when unscrewing the threaded sleeve of the battery power connector of the inverter.

Take out the sealing ring from the terminal.


Unscrew the screw on the terminal used to connect the battery power cable.

Pass the battery power+ cable through the threaded sleeve and the sealing ring, enter the terminal.

Tighten the screw to secure the battery power cable on the terminal (tool: T20 screwdriver, torque: 4Nm).


Push the sealing ring to the terminal.

Tighten the threaded sleeve to the terminal by hand.



- c. Repeat the step b to finish the battery power+ cable connection with the battery power+ terminal of battery SMILE-G3-BAT-8.2P.

- d. Refer to steps b and c, connect the battery power- cable between the inverter and battery SMILE-G3-BAT-8.2P.



For electrical connection between multiple parallel batteries SMILE-G3-BAT-8.2P, please follow the steps below.

a. Take out battery power cables and communication cable from battery packaging.

b. Connect the power cables from battery 2 to battery 1.

Connect the BMS communication cables from battery 2 to battery 1.

When installing more batteries, repeat this electrical connection step.


c. For grounding connection between batteries, please refer to chapter 6.2 Grounding Connection.

NOTICE


Connect the cables between the SMILE-G3-BAT-8.2P batteries, route them from the rear side of the battery when two batteries have been installed side by side.

You can install up to 6 parallel batteries.

Up to two batteries can be stacked per column.










Remove the excess terminal resistor, only retain the terminal resistor of the last parallel battery.



Electrical connection between the Inverter and series batteries (Max. 6):

Please pay attention to the cable type. There are seven kinds of cables.


| No. | Picture | Description |
|-----|---|--|
| 1 |  | Grounding cable between inverter and first series battery connect the grounding point of the upper battery of first column series batteries and the grounding point of the inverter |
| 2 |  | The shortest power cable connect BAT main positive of the first series batteries and the BAT positive of inverter |
| 3 |  | The longest power cable connect BAT main negative of the last series batteries and the BAT negative of inverter |
| 4 |  | The battery communication cable connect the upper communication connector of the upper battery of first column series batteries and the BMS communication port of inverter |
| 5 |  | The medium length power cable connect BAT negative of the bottom battery of first column series batteries and BAT positive of the top battery of second column series batteries |
| 6 |  | The battery communication cable connect the lower communication connector of the bottom battery of first column series batteries and the upper communication connector of the top battery of second column series batteries |
| 7 |  | Grounding cable between two column series batteries connect the grounding point of the bottom battery of first column series batteries and the grounding point of the top or bottom battery of second column series batteries |



Danger to life due to burns caused by electric arcs through short-circuit currents

Short-circuit currents in the battery can cause heat build-up and electric arcs. Heat build-up and electric arcs may result in lethal injuries due to burns.

- Disconnect the battery from all voltages sources prior to performing any work on the battery.
- The upper connector of the lower battery is connected to the lower connector of the upper battery, otherwise the short-circuiting of the battery will occur.
- Observe battery safety information provided in the manual.




Detailed electrical connection between the inverter and series batteries as follows:

- a. Take out all cables from the inverter packaging.
- b. Remove the protective caps from the battery power connectors of the inverter and all series batteries.
- c. Complete the power and communication connection between the upper and lower series batteries of each column first.

Connect the upper power connector of the lower series battery to the lower power connector of the upper series battery.

Connect the upper communication connector of the lower series battery to the lower communication connector of the upper series battery.



- d. Complete the electrical connection between two column series batteries.


Use the provided power cable to connect BAT negative connector of the bottom battery of first column series batteries and BAT positive connector of the top battery of second column series batteries.

Use the provided communication cable to connect the lower communication connector of the bottom battery of first column series batteries and the upper communication connector of the top battery of second column series batteries.



Use the provided grounding cable to connect the grounding point of the bottom battery of first column series batteries and the grounding point of the bottom or top battery of second column series batteries.



- e. Take out the shortest red power cable, connect BAT main positive of series batteries (directly below the inverter) to the BAT positive connector of inverter.

- f. Take out the longest black power cable, connect BAT main negative of series batteries (the last series battery) to the BAT negative connector of inverter.



System wiring diagrams for inverter and series batteries (2 to 6 unit) are as follows:






Accessory cables for distanced horizontal series batteries expansion should be purchased additionally.

6.6. Communication Connection with Inverter

For other communication (AUX2, AUX1, LAN, RRCR, DRM, Meter, RS485) connection, please follow the below steps.

1. Loosen the cable glands on the COM connection cover of the inverter, and then unscrew the 4 screws on the COM connection cover.




2. The pin definition of the communication ports

| | | | | | | | | |
|-------|----------|---------------|----------|-------------|-------------|------------|---------------|---|
| BMS | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| | / | RS485_A4 | / | CAN1_H | CAN1_L | / | RS485_B4 | / |
| RS485 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| | 12V | DEBUG_RXD_COM | GND | RS485_B5 | RS485_A5 | / | DEBUG_TXD_COM | / |
| METER | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| | / | / | RS485_A7 | / | / | RS485_B7 | / | / |
| DRM | 1 | 2 | 3 | 4 | 5 | 6 | / | / |
| | DRED 1/5 | DRED 2/6 | DRED 3/7 | DRED 4/8 | REF GEN/0 | COM LOAD/0 | / | / |
| RRCR | 1 | 2 | 3 | 4 | 5 | 6 | | |
| | K1 | K2 | K3 | K4 | 3.3V | / | | |
| AUX1 | 1 | 2 | 3 | 4 | 5 | 6 | | |
| | DO1_NO | DO1_COM | DO1_NC | DI_negative | DI_positive | GND | | |
| AUX2 | 1 | 2 | 3 | 4 | 5 | 6 | | |
| | DO2_NO | DO2_COM | DO2_NC | DI_negative | DI_positive | GND | | |

3. Pass the communication cables through the cable glands of the COM connection cover. Do not tighten the strain relief nuts of the cable glands yet.

Insert the RJ45 plugs to the relative RJ45 sockets.




- 1) For meter wiring, refer to Section 6.3.5.1 for Meter Wiring.
- 2) If DRM support is specified, the system may only be used in conjunction with a Demand Response Enabling Device (DRED). This ensures that the system implements

the commands from the grid operator for active power limitation at all times. The system and the Demand Response Enabling Device (DRED) must be connected in the same network.

Only DRM0 is available for SMILE-G3 inverter.

- 3) Take out two terminal blocks for AUX connection.


For AUX position definition, please refer to the AUX wiring documentation.



In emergency situations, such as fire, the end user can manually press the EPO (Emergency Power Off) button to shut down the inverter and switch off the battery (except for the PV array). End users or installer should prepare the external EPO.

AUX cable requirements: outdoor shielded copper cable (flexible); recommended conductor cross-section 0.5mm^2 ; conductor ends should be fitted with bootlace ferrules.

To disconnect the AUX connection, rotate the handles on both sides clockwise, unplug the AUX connector, insert a screwdriver (blade width: 1.2mm) into the relative connection position side and unplug the conductor.



4. Place the COM connection cover against the inverter enclosure and tighten the 4 screws. When securing the cover over the communication ports, tighten the cover in place and then lightly push the communication cables into the cover as you tighten the strain relief nuts onto the cables. This will ensure the communication cables are well-seated in the RJ45 ports.


6.7. Mount Covers of the Inverter and Battery

After finishing electrical connection of energy storage system, please follow the below steps.

1. Mount the cable cover of battery


Mount the cable cover of battery SMILE-G3-BAT-8.2P


- Cut a cable hole based on the cabling routing and route the cables through the cable hole.
- Secure the cable cover to the battery housing (tool: T20 screwdriver, torque: 2.0Nm).



Mount the cable cover of the battery SMILE-G3-BAT-3.8S


- Cut a cable hole based on the cabling routing and route the cables through the cable hole.
- Tighten the two support studs for battery cable cover to the battery housing (tool: SW8 hexagon sleeve, torque: 2.5Nm).
- Align the four small protrusions on the right side of the cable cover with the slots on the left side of the battery's front cover, push the cable cover towards the right.
- Secure the cable cover to the battery housing (tool: T20 screwdriver, torque: 1.5Nm) with two screws.






Mount the cable cover of the battery SMILE-G3-BAT-3.6S/4.0S

- Cut a cable hole based on the cabling routing and route the cables through the cable hole.
- Align the top surface of the cable cover to the top surface of the battery housing.
- Align the four small protrusions on the right side of the cable cover to the slots on the left side of the battery's front cover.
- Right push the cable cover to the battery housing till hear the "click" sound.




Disassemble the cable cover of the battery SMILE-G3-BAT-4.0S



2. Mount the covers of the energy storage inverter


Attach the top cover to the inverter.

Place the top cover on top of the inverter, align two locating pins on the inverter housing to the holes on the top cover and slide it forward. The two side screws of the top cover should align to the inverter mounting threaded holes. Secure the top cover to the inverter (tool: T20 screwdriver, torque: 1.6Nm).




Mount left cable cover and right cover of the inverter, please follow the steps below.

- a. Align the hooks on the top side of the right cover to the slots at the right side of the top cover, downwards insert the right cover along the edge of the inverter front cover.




- b. Cut cable holes based on the PV and AC cabling routing and route the cables through the cable holes.





- c. Lift the top surface of the cable cover over the top surface of the inverter about 10mm, place the right edge of the cable cover against the left edge of the front cover of the inverter, downwards push the cable cover along the left edge of the inverter front cover till the two top surfaces are flush. When doing so, insert the bottom positioning pin and two clips into the bottom positioning hole and slots in turn.



7. Power On and Off the System

7.1. Power On the System

- 1) Switch on the battery circuit breaker which is at the left middle of the inverter.
- 2) Switch on the battery circuit breakers of all batteries (located on the left-hand side of the battery).
- 3) For series batteries, please skip this step.

Shortly press the power buttons of all parallel batteries. For more than one parallel battery installed, please press all power buttons within 30 seconds. This power button is located just beside the battery circuit breaker on each parallel battery.

- 4) Switch on the AC circuit breaker between the grid port of the energy storage inverter and the mains grid (this AC circuit breaker should be labelled Main Switch Battery ESS Supply or similar).
- 5) Switch on the AC circuit breaker between the backup port of the energy storage inverter and the backup loads (this AC circuit breaker should be labelled Main Switch Battery ESS Backup or similar).
- 6) Switch on the PV switch between the PV strings and the inverter if there is any.
- 7) Switch on the PV switch at the lower left of the inverter (if there are PV strings directly connected to the energy storage inverter).
- 8) Switch on the AC circuit breaker (if there is any) between any separate PV inverter and the mains grid. These separate PV inverters are also referred to as "AC-coupled PV inverters".



7.2. Power Off the System

⚠ WARNING

After the energy storage system is powered off, the remaining electricity and heat may still cause electric shocks and body burns. Please put on protective gloves and wait 30 minutes for the enclosure to cool down after the system is powered off.

1) S
w
i
t
c

h off the AC circuit breaker between the energy storage inverter and the backup loads.

- 2) Switch off the PV DC Isolator(s) between the PV string and the energy storage inverter if there are any.
- 3) Switch off the PV switch at the lower left of the energy storage inverter (if there are PV strings directly connected to the energy storage inverter).
- 4) For series batteries, please skip this step.
Hold the battery power button located next the battery circuit breaker for 6s to turn off each parallel battery.
- 5) Switch off the battery circuit breakers of all batteries (located on the left-hand side of the battery).
- 6) Switch off the battery circuit breaker which is at the left middle of the inverter.
- 7) Switch off the AC circuit breaker between the energy storage inverter and the mains grid.

8. Commissioning

8.1. Checks before Power-On

| No. | Check Item | Acceptance Criteria |
|-----|-----------------------------------|---|
| 1 | Installation/Mounting Environment | The installation environment is safe and the unit has adequate clearance as per the instruction in this manual as well as in compliance with local standards. The area around the installation should be free from clutter and should not be flood-prone. |
| 2 | Battery and Inverter Mounting | The battery and inverter should be mounted correctly, securely, and reliably. |
| 3 | Wi-Fi Mounting | The Wi-Fi module should be mounted correctly, securely, and reliably. |
| 4 | Cable Layout | Cables should be routed neatly and protected adequately where exposed, in accordance with standards. |
| 5 | Cable Tie | Cable ties should be secured and trimmed evenly and no burr exists. |
| 6 | Grounding | The grounding cables should be connected correctly, securely, and reliably. Impedance/resistance checks should be conducted to confirm reliable grounding connections. |
| 7 | Switch and Breakers Status | The PV switch (if there is any) and battery breakers and any breakers connecting to the system should be OFF. |
| 8 | Cable Connections | The AC cables, PV cables (if there are any), battery power cables, and communication cables should be connected correctly, securely, and reliably. |
| 9 | Unused Ports | Unused power ports and communication ports should be sealed from water or dust ingress by watertight caps. |

8.2. Power On the Product before Commissioning


 **WARNING**



- Before doing electrical connection, please ensure the PV switch & all AC and BAT circuit breakers in the system are switched OFF and cannot be reactivated.
 - Never power on the energy storage system without the correct and reliable installation and electrical connection.
- Check the grid's voltage range and frequency range and the installation (including location, direction and phase sequence) of all CT(s) and/or meter(s).
 - Switch on the battery circuit breaker at the left middle of the energy storage inverter.
 - Switch on the battery circuit breakers of all batteries.
 - Press the battery power button of the parallel battery (For series battery, there is no battery power button)
 - Switch on the external AC circuit breaker between the grid and the energy storage inverter.
 - Please strictly follow the aforementioned steps to power on the system.
Don't switch on the PV switch on the energy storage inverter.
Don't switch on the AC circuit breaker on the PV inverter (if there is any).

8.3. Wi-Fi Module Configuration and Basic Parameters Settings

8.3.1. Wi-Fi Configuration

This section is for user who has an energy storage system with a Wi-Fi module. The AlphaESS App is used to configure the network, set system basic parameter, monitor system operating status and check configuration information.






NOTICE

The system will not be able to connect to the internet without either a physical LAN cable connection or configured Wi-Fi if the Wi-Fi module is used.

8.3.2. Basic Parameters Settings

DC Mode



System Configuration


Progress: ✓ Connect to the hotspot ✓ Router Configuration 3 System Configuration

| | | |
|-------------------------------|---|--|
| Work Mode | DC | Three mode options: DC/AC/Hybrid |
| On Grid PV Capacity | 3 kW | Storage PV capacity: PV installed capacity on the energy storage inverter side |
| Storage PV Capacity | 5 kW | |
| Grid Meter | <input checked="" type="checkbox"/> CT <input type="checkbox"/> Meter | If the grid meter is installed, please select "Meter" for the grid side. If the meter with CT, please select "CT" below. If the meter without CT, please do not select "CT" below. |
| PV Meter | <input checked="" type="checkbox"/> CT <input type="checkbox"/> Meter | |
| Safety Regulations | AS4777.2:2020 | Note: When the safety standard is set as AS4777.2 (Australia and New Zealand), the secondary sub-options can be selected according to the region or local grid company. |
| Regional application standard | Australia A | |
| Max.Feed-in(%) | 100 | You can set the allowable feed-in ratio from 0%-100%. |

Submit

Click "Submit" when the settings are completed.

AC Mode



System Configuration

Progress: ✓ Connect to the hotspot ✓ Router Configuration ? System Configuration

Work Mode AC

On Grid PV Capacity 3 kW

Storage PV Capacity 600 kW

Grid Meter CT Meter

PV Meter CT Meter

Safety Regulations AS4777.2:2020

Regional application standard Australia A

Max.Feed-in(%) 100

Submit

Three mode options: DC/AC/Hybrid

PV installed capacity on the PV-inverter (on-grid) side

If the grid meter is installed, please select "Meter" for the grid side.
If the meter with CT, please select "CT" below.
If the meter without CT, please do not select "CT" below.


Please refer to the above steps to perform the setting of the PV inverter side.

Note: When the safety standard is set as AS4777.2 (Australia and New Zealand), the secondary sub-options can be selected according to the region or local grid company.

You can set the allowable feed-in ratio from 0%-100%.

Click "Submit" when the settings are completed.

Hybrid Mode



System Configuration

Progress: Connect to the hotspot (✓), Router Configuration (✓), System Configuration (3)

Work Mode Hybrid

On Grid PV Capacity 3 kW

Storage PV Capacity 5 kW

Grid Meter CT Meter

PV Meter CT Meter

Safety Regulations AS4777.2:2020 >

Regional application standard Australia A

Max.Feed-in(%) 100

Submit

Click "Submit" when the settings are completed.

Three mode options: DC/AC/**Hybrid**

PV installed capacity on the PV-inverter (on-grid) side

Storage PV installed capacity: PV capacity on the energy storage inverter side

If the grid meter is installed, please select "Meter" for the grid side.
If the meter with CT, please select "CT" below.
If the meter without CT, please do not select "CT" below.
Please refer to the above steps to perform the setting of the PV inverter side.

Note: When the safety standard is set as AS4777.2 (Australia and New Zealand), the secondary sub-options can be selected according to the region or local grid company.

You can set the allowable feed-in ratio from 0%-100%.

CAUTION

The safety standard field must be set correctly

If you select a safety standard that is not valid for your country, region and purpose, it can cause a disturbance in the energy storage system and lead to problems with the Network Operator. When selecting the safety standard, you must always observe the locally applicable standards and directives as well as the properties of the PV system (e.g. PV system size, grid-connection point).

- If you are not sure which safety standard is valid for your country, region or purpose, contact your Network Operator for information on which safety standard should be used.

NOTICE


A Note on setting Feed-In limits with multiple PV systems

If the AlphaESS product is installed with DC-connected Solar Panels as well as with an existing AC-coupled PV system, Installers may need to set a Feed-In limit to comply with Local Regulations.

The Feed-in limit should be set to the total Phase feed-in limit set by the Network Operator, regardless of the size of the existing AC-coupled PV system. Only set the feed-in limit to *zero* if the Network Operator has dictated *zero feed-in* from the house.

8.4. Check System Wiring and Meter Installation


You can directly commission the system after the system configuration process.



Brief wiring diagram of the hybrid system

Detailed operating steps to check system wiring and meter installation as follows:


- 1). Please perform the steps below for the circuit breakers and PV switch in the system
 - a. Switch on the battery circuit breaker of the energy storage inverter.
 - b. Switch on the battery circuit breakers of all batteries.
 - c. Shortly press all power buttons of all batteries within 30 seconds. (For series batteries, please skip this step)
 - d. Switch on the AC circuit breaker between the grid port of the energy storage inverter and the grid.
 - e. Switch on the AC circuit breaker between the backup port of the energy storage inverter and the loads.
 - f. Switch off the PV switch of the energy storage inverter.
 - g. Switch off the AC circuit breaker (if there is any) between the PV inverter and the grid.
 - h. At this moment, the energy storage inverter will enter NORMAL state.
 - i. Please turn off all loads. If you can't, please ensure that there aren't loads of large power fluctuations connected in the system.
 - j. Log on to the AlphaESS App and click to page "My System" and note the current "**Load I**". For example, **Load I** equals 80 W.



2). Operate the App and follow the instructions below to enable function “Charge Batteries from the Grid”.

The image shows two screenshots from the AlphaESS app. The first screenshot, titled 'Function Settings', shows a list of options: 'Charging/Discharging setting', 'Generator Control', 'Backup Box', 'Other Settings', and 'Electricity prices setting'. A red box highlights the 'Charging/Discharging setting' option, and a circled '1' is at the bottom navigation bar. A callout bubble says: 'First click "Function" on the bottom of the home page. Then click "Charging/Discharging Setting"'. The second screenshot, titled 'Charging/Discharging setting', shows various controls. A red box highlights the 'Charge Batteries from Grid' toggle switch, which is turned 'ON'. A callout bubble says: 'Select "ON" to Charge Batteries from the Grid'. Another red box highlights the 'Charging period 1' time selection, with a callout bubble saying: 'Please set the "Charging period 1"'. A third red box highlights the 'Charging stops at SOC (%)' field, which is set to '0'. A callout bubble says: 'Please adjust the SOC to 100.'. A fourth red box highlights the 'Submit' button at the bottom, with a callout bubble saying: 'Click "Submit" when the settings are completed.'. Other settings visible include 'Charging period 2', 'Discharge period 1', 'Discharge period 2', 'Discharging cut off SOC (%)', and 'UPS reserve enable'.

If the formula “Grid Power ≈ **Load I** + Battery Charging Power” fits well, the grid meter installation of the energy storage inverter is correct. Please remember to deactivate the “Charge Batteries from Grid” by clicking “OFF” and save the changes.




If the data doesn't fit well, please perform the troubleshooting below.

| Meter Type | Solution |
|--------------------|--|
| BB Plus | Please refer to the relative system wiring diagram to check the wiring. If the error persists, contact AlphaESS technical service for further check. |
| Meter (without CT) | Check the wiring and location of the grid meter. |
| Meter (with CT) | Check the location, direction, phase sequence and cable connection of the grid CT. |

3). If there isn't a PV inverter in the system, please skip this step.

If a PV inverter exists in the system, switch on the AC breaker between the PV inverter and the grid.

Click the App, turn to page System "Running Information" and check the power value of "PV Inverter Power". If the power value is positive, the meter installation of the PV inverter is correct.



If the power value of "PV Inverter Power" is negative, please perform the troubleshooting below.

| Meter Type | Solution |
|--------------------|--|
| BB Plus | Please refer to the relative system wiring diagram to check the wiring. If the error persists, contact AlphaESS technical service for further check. |
| Meter (without CT) | Check the wiring and location of the PV meter. |
| Meter (with CT) | Check the location, direction, phase sequence and cable connection of the PV CT. |

4). If there are PV modules connected directly to the energy storage inverter, switch on the PV switch of the energy storage inverter.

5). Switch off the AC breaker between the grid port of the energy storage inverter and the grid. At this moment, please check whether the electrical appliance connected to backup side of the energy storage inverter runs normally. Otherwise, please contact AlphaESS service for further check.

CAUTION

During commissioning, if the LEDs on the display panel of the inverter or the battery show red or yellow, please refer to troubleshooting chapter of the Installation, Operation & Maintenance Manual.

6). Congratulation. The whole check of system wiring and meter installation has finished successfully.

8.5. Installing New System and Settings on the App

8.5.1. Download and Install the App


1. Android device users can download the App through major Android application markets such as Google Play.
2. IOS device users can search for “AlphaESS” in the App Store and download the App.



AlphaESS App

8.5.2. Register as an Installer

If you don't have an installer account, please register first.



The image shows three sequential screenshots of the AlphaESS app registration process:

- First Screenshot:** The login/register screen. It features the AlphaESS logo and the tagline "your smart energy". Below the logo are fields for "Account" (Please enter username) and "Password". There are checkboxes for "Remember me" and a link for "Forgot password". At the bottom, there are two buttons: "OK" and "Register". The "Register" button is highlighted with a red rectangle.
- Second Screenshot:** The "Register" screen. It shows the AlphaESS logo and the "Select Role" section with two options: "End user Registration" (with a person icon) and "Installer Registration" (with a person and tools icon). The "Installer Registration" option is selected. Below the options is a link: "Please click here if you are a guest".
- Third Screenshot:** The "Installer Registration" form. It contains several input fields: "License Number" (highlighted with a red rectangle), "Contact number", "Contact Person", "Country", "Post code", "Working Region - State (optional)", "Working Region - City (optional)", "Address", and "Time zone". A callout box with a speech bubble points to the "License Number" field, containing the text: "Get the license No. from your distributor."



If you already have an installer account, please log in directly.

8.5.3. Overview of Functions for Installer Account




8.5.4. Install New System on the App

You can carry out "Install New System" as follows.



For regular installers, please click "Install New System", enter your installer account ID in the "license" field to bind the system to your account and "activate" the system. Enter S/N, check code, license, installation time and click the "save" button.

Only for Australian installers, they need to do more settings. If you are an Australian installer, you will need to fill in the Street (NMI), Suburb (NMI) and Postcode (NMI) fields and the Region field, which has six fixed options (NSW, QLD, VIC, SA, TAS, WA). If SA is selected for Region, two more fields are added which are Agent and NMI. These fields are required in order to meet the requirements of the Network Operator for Dynamic Export and for PV output control by a Relevant Agent.




Australian Installer

Fields that are not marked "optional" need to be filled in. Click "Next".

8.5.5. Instruct the End User to Install the App

Please make sure that end user has downloaded the App, registered the account correctly, and bound the system SN.



8.6. Register on AlphaCloud


8.6.1. Register an Installer Account on AlphaCloud

If you do not already have an Installer account, you can create a new account on our web server for system monitoring purposes. In addition, AlphaESS Warranty is predicated on this connection to our web server.

The data produced prior to registration can be synchronized to the web server.

Step 1: Please open the portal: www.alphaess.com.

Step 2: Please fill in "Username", "Password" and click "Login" if you have already registered.



If not, please register by filling in the following web form;

User registration

| | | |
|---|---|--|
| * User Type End user | * SN Please enter system SN | * SN check code Please enter the SN che |
| * Username someone@example.com | * Zip Code Please enter your zip code | |
| * Password Please enter the password | * Confirm Password Please confirm the password | |
| Language English | * Contact Person Please enter a contact | |
| * Country / Region Please select your coun | Province/State Please select your provin | City/Town Please select your city |
| Address Please enter your address | Contact Number ⓘ Please enter your phone number | |
| * Time Zone Please select a time zone | * Installation Time Please select an installation date | |

Whether to allow automatic update (the automatic upgrade function is to actively update the latest push program to improve the use of the device when the system is online.)

Agree to the above terms [《Terms and Conditions》](#) and [《Privacy Policy》](#)

In this form, all fields with a red star are compulsory.

***Serial Number:** SN (please see the type label of the inverter)


***Username:** 5-15 letters / numbers

***Password:** 5-15 letters / numbers / characters

More details are available in the Online Monitoring Web Server Installers User Manual, which can be downloaded from the AlphaESS homepage.

8.6.2. Install New System on AlphaCloud

Installers who haven't yet registered need to click "Register" to visit the registration page. Please refer to the "AlphaCloud Online Monitoring Web Server Installers User Manual", which you can get from the AlphaESS sales team and get an AlphaESS Installer license number.



Login to your installer account and choose Storage System Maintenance "Install New System" to register new system at Alpha ESS.

The screenshot shows the 'Install New System' form with the following fields:

- *SN:
- *Check Code:
- *License:
- *Create Time:
- Remark: (0/128)
- Attachment:
- Save:

Enter the system S/N, check the code, license, and installation date, then click the "Save" button. The red * indicated a required field. Click the "Browse" button to select any attachment you want to add.

9. Maintenance and Troubleshooting

9.1. Routine Maintenance

Normally, the energy storage system needs no maintenance or calibration.

However, in order to maintain the accuracy of the SOC, it is recommended to perform a full charge calibration for SOC (charge the battery until the charge power is 0W) on the battery at regular intervals (such as two weeks).

Before cleaning, ensure that the system is disconnected from all power sources. Clean the housing, cover and display panel with a soft cloth.

To ensure that the energy storage system can operate properly in the long term, it is advised to perform routine maintenance as described in this chapter.

Maintenance Checklist

| Check Item | Acceptance Criteria | Maintenance Interval |
|------------------------|--|---|
| Product Cleanliness | The enclosure of the inverter should be free from obstacles or dust. | Once every 6 to 12 months |
| Product Visible Damage | The product should be not damaged or deformed. | Once every 6 months |
| Product Running Status | 1. The product should operate without any abnormal sound. 2. All parameters of the product should be set correctly. Perform this check when the product is running. | Once every 6 months |
| Electrical connections | 1. Cables should be securely connected. 2. Cables should be intact, and in particular, the cable jackets touching the metallic surface should not be scratched. 3. Unused cable glands should be blocked by rubber sealing which are secured by pressure caps. | Perform the first maintenance 6 months after the initial commissioning. Thereafter, perform the maintenance once every 6 to 12 months. |

 CAUTION

Risk of burns due to hot enclosure of the inverter



The enclosure of the inverter can get hot during operation.



- Do not touch any parts other than the display panel during operation.
- Wait approximately 30 minutes for the inverter to cool down before cleaning.

9.2. Troubleshooting





9.2.1. Common Errors

Communication Troubleshooting




| LED Indicator | Error Code | LED Display | Description | Troubleshooting |
|---|------------|---|-----------------|--|
| SYS red light is flashing fast | 4 |  | Inverter lost | Inverter communication lost 1. Restart the system. 2. Contact technical service to remotely update the inverter program. 3. If the error persists, contact technical service for further check. |
| SYS red light is glowing. METER light is flashing fast if Grid meter lost. METER light is flashing slow if PV meter lost. METER light is off if all meters lost. | 5 |  | Grid meter lost | Grid side meter lost 1. Check whether the system configuration parameters of AlphaESS App or AlphaCloud are correct and whether the meter is used on the grid side 2. Check whether the communication cable of the grid meter is connected correctly (RS485:3A6B). 3. Check whether the communication configuration parameters of the grid meter are correct (communication address and baud rate). 4. If the error persists, contact technical service for further check. |











| | | | | |
|---|---|---|----------------------|---|
| | 6 |  | <p>PV meter lost</p> | <p>PV inverter side meter lost</p> <ol style="list-style-type: none"> 1. Check whether the system configuration parameters of the AlphaESS App or AlphaCloud are correct and whether the meter is used on the PV inverter side 2. Check whether the communication cable of the meter of PV inverter side is connected correctly (RS485:3A6B). 3. Check whether the communication configuration parameters of the meter on the PV inverter side are correct (communication address and baud rate). 4. If the error persists, contact technical service for further check |
| <p>SYS red light is glowing, BAT light is off</p> | 7 |  | <p>BMS lost</p> | <p>BMS lost</p> <ol style="list-style-type: none"> 1. Check whether the BMS communication connection between the battery and the inverter is correct. 2. Check if the battery is switched on. 3. If the error persists, contact technical service for further check. |

Battery Error Troubleshooting

| LED Indicator | Error Code | LED Display | Description | Troubleshooting |
|--|------------|---|-------------------------------------|---|
| SYS red light is on; BAT light is flashing if the battery is faulty. | 60002 |  | Circuit_Breaker_Open | Try to switch on all batteries' breakers. If the error persists, contact technical service for further check. |
| | 60004 |  | Follower_Battery_Communication_Lost | Check the communication cables between batteries. If the error persists, contact technical service for further check. |
| | 60006 |  | Host_Battery_Communication_Lost | |
| | 60008 |  | Multi_Host_error | |





Inverter Error Troubleshooting

| LED Indicator | Error Code | LED Display | Description | Troubleshooting |
|---------------------------------|------------|---|-------------|--|
| SYS red light is flashing fast. | 100000 |  | Grid_OVP | 1. Check whether grid is abnormal. 2. Confirm whether the grid cable connection is normal. 3. Restart inverter. If the error persists, contact technical service for further check. |
| | 100001 |  | Grid_UVP | 1. Check whether the PV input voltage of PV1, PV2 and PV3 exceeds 1000V. If there is no PV input overvoltage, restart the inverter. |
| | 100002 |  | Grid_OFP | If the error persists, contact technical service for further check. 1. Check whether the PV input voltage of PV1, PV2 and PV3 |






| | | | | |
|--------------------------------|--------|---|------------------|---|
| SYS red light is flashing fast | 100003 |  | Grid_UFP | exceeds 1000V. If there is no PV input overvoltage, restart the inverter. If the error persists, contact technical service for further check. |
| | 100005 |  | BUS_OVP1 | |
| | 100007 |  | Insulation_fault | 1. Check whether PV cable connection is reliable. 2. Check whether PV cable is damaged. If the error persists, contact technical service for further check. |
| | 100008 |  | GFCI_fault | 1. Restart inverter and check whether the error persists. If so, please call technical service. |
| | 100010 |  | Grid_relay_fault | |
| | 100011 |  | Over_Temperature | 1. Check whether the environment around inverter has poor heat dissipation. 2. Confirm whether inverter installation meets the installation requirements. |
| | 100012 |  | PV_Reverse | 1. Check whether the PV terminal of the inverter is reversed. If the PV terminal is right, please call technical service. |
| | 100013 |  | BAT_Reverse | 1. Check whether the BAT terminal of the inverter is reversed. If the BAT terminal is right, please call technical service. |
| | 100017 |  | MPPT1_OVP | 1. Check the PV1/2/3 voltage. If it exceeds 950VDC, reduce the number of PV modules. |
| | 100021 |  | MPPT2_OVP | Check the PV2 voltage. If it exceeds 950V, reduce the number of PV modules |






| | | | | |
|---------------------------------|--------|--|----------------------|--|
| SYS red light is flashing fast. | 100025 | | BAT_OVP | Check whether the actual battery voltage exceeds the battery charge cut-off voltage by more than 20V. |
| | 100026 | | BAT_UVP | 1. Check whether the actual battery voltage is lower than the battery discharge cut-off voltage. If the error persists, contact technical service for further check. |
| | 100027 | | Battery_lost | 1. Confirm whether the battery communication cable connection is normal. 2. check whether the battery voltage sampling value is less than 75V. If the error persists, contact technical service for further check. |
| | 100042 | | Output_short_circuit | 1. Use a multimeter to test the impedance of the off-grid output. If it is low, check whether the wiring is correct. 2. Restart the inverter. If the error persists, contact technical service for further check. |
| | 100043 | | Output_overload | 1. Check whether the load exceeds the rated power. 2. Restart the inverter. If the error persists, contact technical service for further check. |
| | 100052 | | Backup_ovp | 1. Restart the inverter. If the error persists, contact technical service for further check. |
| | 100211 | | Para_CAN | Check the communication cables connection between inverters. If the error persists, contact technical service for further check. |
| | 100213 | | Para_SW_Diff | Check the inverter software versions. If they are inconsistent, upgrade the inverters to the same software version. |

| | | | | |
|---------------------------------|--------|---|-----------------------|--|
| | 100214 |  | Para_Module_Fault | Check parallel inverter mode Settings. Only one host is allowed. |
| | 100216 |  | Para_Multi_Host | |
| SYS red light is flashing fast. | 100403 |  | pe_fault | <p>1. Shutdown inverter and check whether the PE cable and ground cable are properly connected.</p> <p>If the error persists, contact service for further check.</p> |
| | 100412 |  | inv_selfcheck_failure | <p>1. Restart the inverter.</p> <p>If the error persists, contact service for further check.</p> |

Accessories Error Troubleshooting

| LED Indicator | Error Code | LED Display | Description | Troubleshooting |
|--|------------|---|--------------------|--|
| SYS red light is on, METER light is flashing fast. | 39 |  | EV Charger Lost | EV Charger lost 1. Check whether the EV communication connection between the EV charger and the inverter is normal. 2. Check whether the batteries are switched on. If the error persists, contact technical service for further check. |
| | 200000 |  | Relay OTP | 1. Unplug the charging connector of the EV charger, and wait for about 10 minutes before plugging it back in. If the error persists, contact technical service for further check. |
| | 200001 |  | Output overload | 1. Check whether the load exceeds the rated power. 2. Restart the inverter. If the error persists, contact technical service for further check. |
| | 200010 |  | AC leakage current | 1. Unplug the charging connector of the EV charger, and wait for about 10 minutes before plugging it back in. If the error persists, contact technical service for further check. |
| | 200011 |  | Input terminal OTP | 1. Unplug the charging connector of the EV charger, and wait for about 10 minutes before plugging it back in. If the error persists, contact technical service for further check. |


| | | | | |
|--|--------|---|----------------|---|
| SYS red light is on, METER light is flashing fast. | 200014 |  | Relay abnormal | 1. The EV charger has a hardware failure and need to be replaced, please contact technical service. |
| | 200015 |  | Ground fault | 1. Check whether the grounding method is correct. If there is no grounding or the grounding method is wrong, please follow the correct grounding method. |
| | 200016 |  | Reverse phase | 1. Shut off the leakage current protection switch of the power distribution cabinet immediately. 2. Check whether the AC input/output cable connection is normal, and verify whether there is an inverse connection of L/N input cables. |

NOTICE

1. The four LEDs in the first row are system (SYS), battery (BAT), meter (METER), and communication (COM).
2. The five LEDs in the second row serve two functions:
 - 1) During normal system operation, they indicate the SOC operation status of the batteries connected in this energy storage system.
 - 2) During abnormal system operation, they display corresponding error codes. Each light represents a number, with values of 1, 2, 4, 8, and 16, from right to left.

9.2.2. Battery Protection Description for SMILE-G3-BAT-8.2P

The three LED indicators on the left front provide information about the protection status of the battery.



| LED Display State | Description | Troubleshooting |
|-------------------|---------------------------|--|
| | High temperature | Stop discharging and charging until this display state is eliminated and wait for the temperature to drop. |
| | Low temperature discharge | Stop discharging until this display state is eliminated and wait for the temperature to rise. |
| | Overcurrent charge | Wait for automatic recovery. If this protection state hasn't be solved, please call technical service. |
| | Overcurrent discharge | Wait for automatic recovery. If this protection state hasn't be solved, please call technical service. |
| | Cell under voltage | Stop discharging and call technical service immediately. |
| | Low temperature charge | Stop charging until this protection state is eliminated and wait for the temperature to rise. |

NOTICE

During working mode, if the protection status "Cell under voltage" appears, please press the power button of the battery 5 times within 10 seconds. The BMS will be forced to turn on the MOSFET of discharge so that the inverter can detect the battery's open voltage and begin charging the battery.









9.2.3. Battery Protection Description for Series Battery

The three LED indicators on the front cover provide information about the protection status of the battery.


 : Yellow LEDs flashing

 : Yellow LEDs on

 : Yellow LEDs off

| LED Display State | Description | Troubleshooting |
|---|---------------------------|---|
|  | Temperature difference | Wait for automatic recovery. If this protection state persists, please call technical service. |
|  | High temperature | Stop discharging and charging until this protection state is eliminated. Wait for the temperature to drop. |
|  | Low temperature discharge | Stop discharging until this protection state is eliminated. Wait for the temperature to rise. |
|  | Overcurrent charge | Wait for automatic recovery. |
|  | Overcurrent discharge | If this protection state hasn't be solved, please call technical service. |
|  | Cell overvoltage | Wait for automatic recovery. If this protection state persists for a long time, please call technical service. |
|  | Cell under voltage | Stop discharging and call technical service immediately. |
|  | Low temperature charge | Stop charging until this protection state is eliminated. Wait for the temperature to rise. |

 **NOTICE**


During work mode, if the protection status "Cell under voltage"  appears, please take the following action:

First, switch off the breaker which is located on the left side of the battery, switch on the breaker and wait for 3~5s, switch off the breaker, then switch on the breaker and wait for 3~5s, switch off the breaker, at last switch on the breaker of the battery.

The BMS will be forced to turn on the MOSFET of discharge, allowing the energy storage inverter to detect the battery's open voltage and begin charging it.

9.2.4. Battery Error Description

The three LED indicators on the front cover provide information about the error status of the battery.



| LED Display State | Description | Troubleshooting |
|-------------------|-------------------------------|---|
| | Hardware error | Wait for automatic recovery. If this error persists, please call AlphaESS technical service. |
| | Hardware error | |
| | Circuit breaker open | Switch on circuit breaker after powering off the battery. |
| | LMU disconnect (Follower) | Reconnect the BMS communication cable. |
| | SN missing | Please call AlphaESS technical service. |
| | LMU disconnect (Host) | Reconnect the BMS communication cable. |
| | Software version inconsistent | Please call AlphaESS technical service. |
| | Multi-Host | Restart all batteries. |
| | MOS over temperature | Power off the battery and power on the battery after 30 minutes. |
| | Insulation fault | Restart battery. In case this error persists, please call AlphaESS technical service. |
| | Total voltage fault | Restart battery. In case this error persists, please call AlphaESS technical service. |
| | Precharge failure | Restart battery. In case this error persists, please call AlphaESS technical service. |

10. Product Removal & Return

10.1. Removing the Product

Procedure

- Step 1: Power off the energy storage system as described in Chapter 7.2 Power off the System.
- Step 2: Disconnect all cables from the system, including communication cables, PV power cables, battery power cables, AC cables, and PE cables.
- Step 3: Remove the Wi-Fi module.
- Step 4: Remove the cable covers of the inverter and the battery.
Remove the right cover of the inverter.
- Step 5: Remove the inverter from the top of the battery.
- Step 6: Remove the battery wall brackets.
- Step 7: Remove the batteries.

10.2. Packing the Product

If the original packaging is available, put the product inside it and then seal it using adhesive tape.

If the original packaging is not available, put the product inside a suitable cardboard box and seal it properly.

10.3. Disposing of the Product

- If the product's service life expires, dispose of it according to the local disposal rules for electrical equipment and electronic waste.
- Dispose of the packaging and replaced parts according to the rules at the installation site where the device is installed.
- Do not dispose the product with regular household waste.



11. Technical Data

11.1. Datasheet of Inverter SMILE-G3 Three Phase Inverter

| Item | G3-T12-INV | G3-T15-INV | G3-T20-INV |
|---|------------------------|------------|------------|
| Input DC (PV Side) | | | |
| Recommended Max. PV Power | 24 kW | 30 kW | 40 kW |
| Max. PV Input Voltage | 1000 V | | |
| Rated Voltage | 700 V | | |
| Start-up Voltage | 220 V | | |
| MPPT Voltage Range | 200 ~ 850 V | | |
| Max. Input Current per MPPT | 18 A /18 A /18 A | | |
| Max. Short Circuit Current per MPPT | 22.5 A /22.5 A /22.5 A | | |
| MPPT Number | 3 | | |
| Max. Input Strings Number per MPPT | 1 | | |
| Surge Category in Accordance with IEC 62109-1 | II | | |
| Battery | | | |
| Battery Type | LFP (LiFePO4) | | |
| Battery Voltage Range | 160 - 650 V | | |
| Max. Charge Power | 12 kW | 15 kW | 20 kW |
| Max. Discharge Power | 12 kW | 15 kW | 20 kW |
| Max. Charge Current | 60 A | | |
| Max. Discharge Current | 60 A | | |
| Communication | CAN | | |
| Output AC (Back-up, On-Grid) | | | |
| Rated Output Power | 12 kW | 15 kW | 20 kW |
| Rated Apparent Output Power | 12 kVA | 15 kVA | 20 kVA |
| Rated Output Current | 17.4A | 21.7 A | 29 A |
| Max. Continuous Output Power | 13.2 kW | 16.5 kW | 22 kW |
| Max. Continuous Output Apparent Power | 13.2 kVA | 16.5 kVA | 22 kVA |
| Max. Output Current | 19.1 A | 23.9 A | 31.9 A |
| Rated Output Voltage | 3L/N/PE, 380/400 V | | |
| Rated Frequency | 50 Hz | | |
| Output AC (Back-up, Off-Grid) | | | |
| Rated Output Power | 12 kW | 15 kW | 20 kW |
| Rated Apparent Output Power | 12 kVA | 15 kVA | 20 kVA |
| Rated Output Current | 17.4A | 21.7 A | 29 A |
| Max. Continuous Output Power | 13.2 kW | 16.5 kW | 22 kW |
| Max. Apparent Output Power | 13.2 kVA | 16.5 kVA | 22 kVA |
| Output Power < 10 Minutes | 14.4 kW | 18 kW | 24 kW |

| | | | |
|--|-----------------------------------|----------|--------|
| Output Apparent Power < 10 Minutes | 14.4 kVA | 18 kVA | 24 kVA |
| Output Power < 10 s | 18 kW | 22.5 kW | 26 kW |
| Output Apparent Power < 10 s | 18 kVA | 22.5 kVA | 26 kVA |
| Back-up Switch Time | <20 ms | | |
| Rated Output Voltage | 3L/N/PE, 380/400 V | | |
| Rated Frequency | 50 Hz | | |
| Input AC (Grid Side) | | | |
| Rated Output Voltage | 3L/N/PE, 380/400V | | |
| Rated Frequency | 50 Hz | | |
| Max. Input Power | 17 kW | 20kW | 25 kW |
| Max. Input Current | 24.6A | 29 A | 36.2 A |
| Output AC (Grid side) | | | |
| Rated Output Power | 12 kW | 15 kW | 20 kW |
| Max. Apparent Output Power at $\cos \varphi = 1$ | 13.2 kVA | 16.5 kVA | 22 kVA |
| Operation Phase | Three Phase | | |
| Rated Grid Voltage | 3L/N/PE, 380/400V | | |
| Grid Voltage Range | 180 ~ 270 V | | |
| Rated Grid Frequency | 50 Hz | | |
| Rated Grid Output Current | 17.4A | 21.7 A | 29 A |
| Power Factor | >0.99 (0.8 Leading - 0.8 Lagging) | | |
| Protection Class | I | | |
| Oversvoltage Category | III | | |
| Surge Category in Accordance with IEC 60664-1 | II | | |
| Efficiency | | | |
| Max. Efficiency, η_{max} | 97.6% | 98% | 98% |
| European Weighted Efficiency, η_{EU} | 97.2% | 97.6% | 97.6% |
| Protection | | | |
| Anti-Islanding Protection | Integrated | | |
| Insulation Resistor Detection | Integrated | | |
| Residual Current Monitoring Unit | Integrated | | |
| Output Over-Current Protection | Integrated | | |
| Output Short Protection | Integrated | | |
| Output Oversvoltage Protection | Integrated | | |
| PV Reverse Polarity Protection | Integrated | | |
| PV Oversvoltage Protection | Integrated | | |
| PV Switch | Integrated | | |
| Battery Breaker | Integrated | | |
| General Data | | | |
| Dimensions (W*H*D) | 610*610*244 mm | | |



| | |
|--|----------------------|
| Weight | 39 kg |
| Topology | Transformerless |
| Operation Temperature Range | -25 ~ +60 °C |
| Max. Permissible Value for Relative Humidity (Condensing) | 100% |
| Ingress Protection | IP65 |
| Display | LED |
| Noise Emission | <50 dB(A) @1m |
| Cooling Method | Fan Cooling |
| Max. Operating Altitude above MSL | 3000 m |
| Features | |
| PV Connection | Vaconn D4 Connectors |
| Grid Connection | Plug-in Connector |
| Backup Connection | Plug-in Connector |
| BAT Connection | Screw Terminal |
| Communication | LAN, Wi-Fi |

11.2. Datasheet of Battery

11.2.1. Datasheet of Battery SMILE-G3-BAT-8.2P

| Model | SMILE-G3-BAT-8.2P |
|-----------------------------|---|
| Battery Type | LFP (LiFePO ₄) |
| Weight | 78.3 kg |
| Dimensions (W*H*D) | 610*793*212 mm |
| Ingress Protection | IP21 |
| Installed Energy | 8.2 kWh |
| Usable Energy | 7.8 kWh |
| Depth of Discharge | 95% |
| Nominal Voltage | 256 V |
| Operating Voltage Range | 240 to 288 V |
| Max. Charge Current* | 32 A |
| Max. Discharge Current* | 32 A |
| Operating Temperature Range | Charge: 0 < T ≤ 55°C Discharge: -10 < T ≤ 55°C |
| Monitoring Parameters | System voltage, current, cell voltage, cell temperature, PCBA temperature |
| BMS Communication | CAN |
| System | |
| Safety | IEC62619 / IEC63056 / IEC62040 |
| Transportation | UN38.3 |

* Max. charge/discharge current derating may occur with changes in temperature and SOC.

11.2.2. Datasheet of Battery SMILE-G3-BAT-3.6S

| Model | SMILE-G3-BAT-3.6S |
|-----------------------------|---|
| Battery Type | LFP (LiFePO ₄) |
| Weight | 43.2 kg |
| Dimensions (W*H*D) | 610*435*212.5 mm |
| Ingress Protection | IP65 |
| Installed Energy | 3.6 kWh |
| Usable Energy | 3.6 kWh |
| Depth of Discharge | 100% |
| Nominal Voltage | 96 V |
| Operating Voltage Range | 90 to 108 V |
| Max. Charge Current* | 42 A |
| Max. Discharge Current* | 42 A |
| Operating Temperature Range | Charge: $0 < T \leq 60^{\circ}\text{C}$ Discharge: $-10 < T \leq 60^{\circ}\text{C}$ |
| Monitoring Parameters | System voltage, current, cell voltage, cell temperature, PCBA temperature |
| BMS Communication | CAN |
| System | |
| Safety | IEC62619 / IEC63056 / IEC62040 |
| Transportation | UN38.3 |

* Max. charge/discharge current derating may occur with changes in temperature and SOC.

SMILE-G3-BAT-3.6S is only for Greece market.

11.2.3. Datasheet of Battery SMILE-G3-BAT-3.8S

| Model | SMILE-G3-BAT-3.8S |
|-----------------------------|---|
| Battery Type | LFP (LiFePO ₄) |
| Weight | 38.5 kg |
| Dimensions (W*H*D) | 610*435*212 mm |
| Ingress Protection | IP21 |
| Installed Energy | 3.84 kWh |
| Usable Energy | 3.65 kWh |
| Depth of Discharge | 95% |
| Nominal Voltage | 96 V |
| Operating Voltage Range | 90 to 108 V |
| Max. Charge Current* | 40 A |
| Max. Discharge Current* | 40 A |
| Operating Temperature Range | Charge: 0<T≤50°C Discharge: -10<T≤50°C |
| Monitoring Parameters | System voltage, current, cell voltage, cell temperature, PCBA temperature |
| BMS Communication | CAN |
| System | |
| Safety | IEC62619 / IEC63056 / IEC62040 |
| Transportation | UN38.3 |

* Max. charge/discharge current derating may occur with changes in temperature and SOC.

11.2.4. Datasheet of Battery SMILE-G3-BAT-4.0S


| Model | SMILE-G3-BAT-4.0S |
|-----------------------------|---|
| Battery Type | LFP (LiFePO ₄) |
| Weight | 43.2 kg |
| Dimensions (W*H*D) | 610*435*212.5 mm |
| Ingress Protection | IP65 |
| Installed Energy | 4.0 kWh |
| Usable Energy | 3.8 kWh |
| Depth of Discharge | 95% |
| Nominal Voltage | 96 V |
| Operating Voltage Range | 90 to 108 V |
| Max. Charge Current* | 42 A |
| Max. Discharge Current* | 42 A |
| Operating Temperature Range | Charge: 0<T≤60°C Discharge: -10<T≤60°C |
| Monitoring Parameters | System voltage, current, cell voltage, cell temperature, PCBA temperature |
| BMS Communication | CAN |
| System | |
| Safety | IEC62619 / IEC63056 / IEC62040 |
| Transportation | UN38.3 |

* Max. charge/discharge current derating may occur with changes in temperature and SOC.

Appendix 1: System Wiring Diagram


01


SMILE-G3-T12/T15/T20 System Wiring Diagram with CHINT Electricity Meter DTSU666 (without CT), EU




02

SMILE-G3-T12/T15/T20 System Wiring Diagram with CHINT Electricity Meter DTSU666 (with CT), EU








01

SMILE-G3-T12/T15/T20 System Wiring Diagram with CHINT Electricity Meter DTSU666 (without CT)

NOTICE
(Only for Australia and New Zealand installation sites)




This applies to an existing PV system.

02

SMILE-G3-T12/T15/T20 System Wiring Diagram with CHINT Electricity Meter DTSU666 (with CT)


NOTICE
(Only for Australia and New Zealand installation sites)




This applies to an existing PV system.

01

SMILE-G3-T112/T15/T20 System Wiring Diagram with CHINT Electricity Meter DTSU666 (without CT), Africa





Appendix 2: Regional Application Standard

Please check with your local grid company and choose the corresponding regional application standard, the power quality modes Volt-VAR and Volt-Watt will be running automatically. (Only for regions with AS/NZW 4777.2 Safety Standard)

| Regional Application Standard | Electric Company |
|-------------------------------|--------------------|
| Australia A | N/A |
| Australia B | N/A |
| Australia C | N/A |
| New Zealand | N/A |
| Vector | New Zealand Vector |

 @AlphaEnergyStorageSystem  @AlphaESS  @alpha_ess  @AlphaESS  www.alphaess.com

Alpha ESS Co., Ltd.

 +86 513 8060 6891
 info@alpha-ess.com
 www.alphaess.com
 No. 1086 Bihua Road, Tongzhou District, Nantong City, Jiangsu Province, China

Alpha ESS Europe GmbH

 +49 610 3459 1601
 europe@alpha-ess.de
 www.alphaess.de
 Paul-Ehrlich-Straße 1a, Langen, Hessen D-63225 Germany




Alpha ESS UK Co., Ltd

 +44 330 043 2610
 info@alpha-ess.com
 Drake house, Long street, Dursley, gl11 4hh UK

Alpha ESS NZ Ltd.

 +64 0800 769 377
 info@alpha-ess.com
 www.alpha-ess.co.nz
 19 Arrenway Drive, Albany, 0630, New Zealand

Alpha ESS South Africa (Pty.) Ltd.

 +27 010 745 5653
 measervice@alpha-ess.com
 Johannesburg, South Africa

Alpha ESS Japan, Inc.

 info@alpha-ess.com
 www.alphaess.jp

Alpha ESS International Pte. Ltd.

 +65 6513 1125 / +65 6513 1126
 Singapore@alpha-ess.com
 2 Corporation Road #01-06A Corporation Place 618494 Singapore

Alpha ESS Australia Pty. Ltd.

 +61 02 9000 7676
 techsupport@alphaess.au
 www.alphaess.au
 8/15-21 Gibbes Street, Chatswood, NSW 2067 Australia



Alpha ESS Italy S.r.l.

 +39 339 462 4288
 info@alphaess.it
 www.alphaess.it
 Via Del Molinuzzo 83, 59100 Prato (PO), Italy

Alpha ESS USA, Inc.

 +1 800 220 0725 (Service Inquiries)
 service@alphaess.us
 www.alphaess.us
2180 S Ivanhoe St. Unit 5 Denver.CO 80222 USA

Alpha ESS Korea Co., Ltd

 info@alpha-ess.com
 2F, 19-4, Nohyeong 11-gil, Jeju-si, Jeju-do, Republic of Korea